

# System SLIO

FM | 054-1CB00 | Manual

HB300 | FM | 054-1CB00 | en | 18-07

Motion Module - 2xDC - FM 054



YASKAWA Europe GmbH  
Hauptstraße 185  
65760 Eschborn  
Germany  
Tel.: +49 6196 569-300  
Fax: +49 6196 569-398  
Email: [info@yaskawa.eu.com](mailto:info@yaskawa.eu.com)  
Internet: [www.yaskawa.eu.com](http://www.yaskawa.eu.com)

## Table of contents

<b>1</b>	<b>General</b> .....	<b>5</b>
1.1	Copyright © YASKAWA Europe GmbH.....	5
1.2	About this manual.....	6
1.3	Safety information.....	6
<b>2</b>	<b>Basics and mounting</b> .....	<b>8</b>
2.1	Safety notes for the user.....	8
2.2	System conception.....	9
2.2.1	Overview.....	9
2.2.2	Components.....	10
2.2.3	Accessories.....	13
2.2.4	Hardware revision.....	15
2.3	Dimensions.....	15
2.4	Mounting 8x periphery modules.....	18
2.5	Mounting 16x periphery modules.....	21
2.6	Wiring 8x periphery modules.....	23
2.7	Wiring 16x periphery modules.....	25
2.8	Wiring power modules.....	26
2.9	Demounting 8x periphery modules.....	31
2.10	Demounting 16x periphery modules.....	34
2.11	Easy Maintenance.....	37
2.12	Trouble shooting - LEDs.....	38
2.13	Industrial security and installation guidelines.....	39
2.13.1	Industrial security in information technology.....	39
2.13.2	Installation guidelines.....	41
2.14	General data for the System SLIO.....	43
2.14.1	Use in difficult operating conditions.....	45
<b>3</b>	<b>Hardware description</b> .....	<b>46</b>
3.1	Properties.....	46
3.2	Structure.....	47
3.3	Block diagram.....	50
3.4	Technical data.....	51
<b>4</b>	<b>Deployment</b> .....	<b>55</b>
4.1	Basics.....	55
4.1.1	DC motor module.....	56
4.1.2	Structure of a positioning control.....	56
4.1.3	Encoder - signal evaluation.....	57
4.2	Commissioning.....	59
4.2.1	Installation.....	59
4.2.2	Inspections and tests before the test operation.....	59
4.2.3	Start-up of the System SLIO motion module.....	59
4.3	Connecting a motor.....	61
4.3.1	Connection options.....	61
4.4	Drive profile.....	62
4.4.1	Overview.....	62
4.4.2	States.....	63
4.4.3	Operating modes.....	64
4.5	Homing.....	65

4.5.1	Homing by means of a homing switch.....	67
4.5.2	Homing to current position.....	69
4.5.3	Homing by means of current limitation.....	70
4.6	PtP positioning profile.....	72
4.6.1	Examples.....	78
4.7	Velocity profile.....	84
4.8	Torque control.....	88
4.9	Deployment I/O1...I/O4.....	91
4.9.1	Objects.....	92
4.9.2	Usage as input for encoder.....	92
4.10	Brake control.....	95
4.11	In-/Output area.....	95
4.12	Acyclic channel.....	98
4.13	Parameter data.....	99
4.13.1	Parameter.....	99
4.14	Scaling and units.....	101
4.15	Monitoring and error reaction.....	101
4.15.1	Overview.....	101
4.15.2	Monitoring.....	103
4.16	Diagnostics and interrupt.....	106
<b>5</b>	<b>Object dictionary.....</b>	<b>108</b>
5.1	Use.....	108
5.2	Objects.....	109
5.2.1	Overview.....	109
5.2.2	Information about the product - 0x1000...0x1018.....	113
5.2.3	Passwords and security - 0x1100.....	114
5.2.4	System command - 0x6100.....	115
5.2.5	Digital inputs I/O1...I/O4 - 0x7100.....	115
5.2.6	Digital output I/O1...I/O4 - 0x7200.....	117
5.2.7	Driver command - 0x8100.....	120
5.2.8	Configure drive - 0x8180.....	128
5.2.9	Options - 0x8200.....	129
5.2.10	Operating modes - 0x8280.....	130
5.2.11	Homing - 0x8300.....	131
5.2.12	Parameter for the PtP positioning profile - 0x8400.....	135
5.2.13	Positions and limit values - 0x8480.....	136
5.2.14	Velocities and limit values - 0x8500.....	140
5.2.15	Acceleration and deceleration - 0x8580.....	143
5.2.16	Currents - 0x8600.....	144
5.2.17	Voltages - 0x8680.....	148
5.2.18	Temperatures - 0x8780.....	151
5.2.19	Motor data - 0x8C00.....	153
5.2.20	Encoder resolution - 0x8F00.....	154



# 1 General

## 1.1 Copyright © YASKAWA Europe GmbH

### All Rights Reserved

This document contains proprietary information of Yaskawa and is not to be disclosed or used except in accordance with applicable agreements.

This material is protected by copyright laws. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to Yaskawa) except in accordance with applicable agreements, contracts or licensing, without the express written consent of Yaskawa and the business management owner of the material.

For permission to reproduce or distribute, please contact: YASKAWA Europe GmbH, European Headquarters, Hauptstraße 185, 65760 Eschborn, Germany

Tel.: +49 6196 569 300

Fax.: +49 6196 569 398

Email: [info@yaskawa.eu.com](mailto:info@yaskawa.eu.com)

Internet: [www.yaskawa.eu.com](http://www.yaskawa.eu.com)

### EC conformity declaration

Hereby, YASKAWA Europe GmbH declares that the products and systems are in compliance with the essential requirements and other relevant provisions. Conformity is indicated by the CE marking affixed to the product.

### Conformity Information

For more information regarding CE marking and Declaration of Conformity (DoC), please contact your local representative of YASKAWA Europe GmbH.

### Trademarks

SLIO and SPEED7 are registered trademarks of YASKAWA Europe GmbH.

SIMATIC is a registered trademark of Siemens AG.

All other trademarks, logos and service or product marks specified herein are owned by their respective companies.

### General terms of use

Every effort has been made to ensure that the information contained in this document was complete and accurate at the time of publishing. We cannot guarantee that the information is free of errors, and we reserve the right to change the information at any time. There is no obligation to inform the customer about any changes. The customer is requested to actively keep his documents up to date. The customer is always responsible for the deployment of the products with the associated documentation, taking into account the applicable directives and standards.

This documentation describes all hardware and software units and functions known today. It is possible that units are described that do not exist at the customer. The exact scope of delivery is described in the respective purchase contract.

### Document support

Contact your local representative of YASKAWA Europe GmbH if you have errors or questions regarding the content of this document. You can reach YASKAWA Europe GmbH via the following contact:

Email: [Documentation.HER@yaskawa.eu.com](mailto:Documentation.HER@yaskawa.eu.com)

### Technical support

Contact your local representative of YASKAWA Europe GmbH if you encounter problems or have questions regarding the product. If such a location is not available, you can reach the Yaskawa customer service via the following contact:

YASKAWA Europe GmbH,

European Headquarters, Hauptstraße 185, 65760 Eschborn, Germany

Tel.: +49 6196 569 500 (hotline)

Email: [support@yaskawa.eu.com](mailto:support@yaskawa.eu.com)

## 1.2 About this manual

### Objective and contents

This manual describes the FM 054-1CB00 of the System SLIO.

- It describes the structure, configuration and application.
- The manual is targeted at users who have a background in automation technology.
- The manual consists of chapters. Each chapter describes a completed topic.
- For guidance, the manual provides:
  - An overall table of contents at the beginning of the manual.
  - References with pages numbers.



*To be able to return to the previous view from a reference in the PDF, you should activate the page navigation in your PDF viewer.*

### Validity of the documentation

Product	Order no.	as of state:	
FM 054 2xDC	054-1CB00	HW: 01	FW: V1.1.2

### Icons Headings

Important passages in the text are highlighted by following icons and headings:



#### **DANGER!**

Immediate or likely danger. Personal injury is possible.



#### **CAUTION!**

Damages to property is likely if these warnings are not heeded.



*Supplementary information and useful tips.*

## 1.3 Safety information

### Applications conforming with specifications

The system is constructed and produced for:

- communication and process control
- general control and automation tasks
- industrial applications
- operation within the environmental conditions specified in the technical data
- installation into a cubicle



#### **DANGER!**

This device is not certified for applications in

- in explosive environments (EX-zone)

**Documentation**

The manual must be available to all personnel in the

- project design department
- installation department
- commissioning
- operation

**CAUTION!**

**The following conditions must be met before using or commissioning the components described in this manual:**

- Hardware modifications to the process control system should only be carried out when the system has been disconnected from power!
- Installation and hardware modifications only by properly trained personnel.
- The national rules and regulations of the respective country must be satisfied (installation, safety, EMC ...)

**Disposal**

**National rules and regulations apply to the disposal of the unit!**

## 2 Basics and mounting

### 2.1 Safety notes for the user



#### **DANGER!**

##### **Protection against dangerous voltages**

- When using System SLIO modules, the user must be protected from touching hazardous voltage.
- You must therefore create an insulation concept for your system that includes safe separation of the potential areas of ELV and hazardous voltage.
- Here, observe the insulation voltages between the potential areas specified for the System SLIO modules and take suitable measures, such as using PELV/SELV power supplies for System SLIO modules.

#### **Handling of electrostatic sensitive modules**

The modules are equipped with highly integrated components in MOS technology. These components are highly sensitive to over-voltages that occur, e.g. with electrostatic discharge. The following symbol is used to identify these hazardous modules:



The symbol is located on modules, module racks or on packaging and thus indicates electrostatic sensitive modules. Electrostatic sensitive modules can be destroyed by energies and voltages that are far below the limits of human perception. If a person who is not electrically discharged handles electrostatic sensitive modules, voltages can occur and damage components and thus impair the functionality of the modules or render the modules unusable. Modules damaged in this way are in most cases not immediately recognized as faulty. The error can only appear after a long period of operation. Components damaged by static discharge can show temporary faults when exposed to temperature changes, vibrations or load changes. Only the consistent use of protective devices and responsible observance of the handling rules can effectively prevent malfunctions and failures on electrostatic sensitive modules.

#### **Shipping of modules**

Please always use the original packaging for shipping.

#### **Measurement and modification of electrostatic sensitive modules**

For measurements on electrostatic sensitive modules the following must be observed:

- Floating measuring instruments must be discharged before use.
- Measuring instruments used must be grounded.

When modifying electrostatic sensitive modules, ensure that a grounded soldering iron is used.




#### **CAUTION!**

When working with and on electrostatic sensitive modules, make sure that personnel and equipment are adequately grounded.

## 2.2 System conception

### 2.2.1 Overview

The System SLIO is a modular automation system for assembly on a 35mm mounting rail. By means of the periphery modules with 2, 4, 8 and 16 channels this system may properly be adapted matching to your automation tasks. The wiring complexity is low, because the supply of the DC 24V power section supply is integrated to the backplane bus and defective modules may be replaced with standing wiring. By deployment of the power modules in contrasting colors within the system, further isolated areas may be defined for the DC 24V power section supply, respectively the electronic power supply may be extended with 2A.



## 2.2.2 Components


- CPU (head module)
- Bus coupler (head module)
- Line extension
- 8x periphery modules
- 16x periphery modules
- Power modules
- Accessories



### CAUTION!

Only Yaskawa modules may be combined. A mixed operation with third-party modules is not allowed!

### CPU 01xC



With the CPU 01xC electronic, input/output components and power supply are integrated to one casing. In addition, up to 64 periphery modules of the System SLIO can be connected to the backplane bus. As head module via the integrated power module for power supply CPU electronic and the I/O components are supplied as well as the electronic of the periphery modules, which are connected via backplane bus. To connect the power supply of the I/O components and for DC 24V power section supply of via backplane bus connected periphery modules, the CPU has removable connectors. By installing of up to 64 periphery modules at the backplane bus, these are electrically connected, this means these are assigned to the backplane bus, the electronic modules are power supplied and each periphery module is connected to the DC 24V power section supply.

### CPU 01x




With this CPU 01x, CPU electronic and power supply are integrated to one casing. As head module, via the integrated power module for power supply, CPU electronic and the electronic of the connected periphery modules are supplied. The DC 24V power section supply for the linked periphery modules is established via a further connection of the power module. By installing of up to 64 periphery modules at the backplane bus, these are electrically connected, this means these are assigned to the backplane bus, the electronic modules are power supplied and each periphery module is connected to the DC 24V power section supply.



### CAUTION!

CPU part and power module may not be separated!  
Here you may only exchange the electronic module!

### Bus coupler




With a bus coupler bus interface and power module is integrated to one casing. With the bus interface you get access to a subordinated bus system. As head module, via the integrated power module for power supply, bus interface and the electronic of the connected periphery modules are supplied. The DC 24V power section supply for the linked periphery modules is established via a further connection of the power module. By installing of up to 64 periphery modules at the bus coupler, these are electrically connected, this means these are assigned to the backplane bus, the electronic modules are power supplied and each periphery module is connected to the DC 24V power section supply.



#### CAUTION!

Bus interface and power module may not be separated!  
Here you may only exchange the electronic module!

### Line extension




In the System SLIO there is the possibility to place up to 64 modules in on line. By means of the line extension you can divide this line into several lines. Here you have to place a line extension master at each end of a line and the subsequent line has to start with a line extension slave. Master and slave are to be connected via a special connecting cable. In this way, you can divide a line on up to 5 lines. For each line extension the maximum number of pluggable modules at the System SLIO bus is decreased by 1. To use the line extension no special configuration is required.



*Please note that some modules do not support line extensions due to the system. For more information, see the 'System SLIO - Compatibility List' at [www.yaskawa.eu.com](http://www.yaskawa.eu.com)*

### Periphery modules




The periphery modules are available in the following 2 versions, whereby of each the electronic part can be replaced with standing wiring:

- 8x periphery module for a maximum of 8 channels.
- 16x periphery module for a maximum of 16 channels.


**8x periphery modules**

Each 8x periphery module consists of a *terminal* and an *electronic module*.




- 1 Terminal module
- 2 Electronic module

**Terminal module**



The *terminal* module serves to carry the electronic module, contains the backplane bus with power supply for the electronic, the DC 24V power section supply and the staircase-shaped terminal for wiring. Additionally the terminal module has a locking system for fixing at a mounting rail. By means of this locking system your system may be assembled outside of your switchgear cabinet to be later mounted there as whole system.


**Electronic module**



The functionality of a periphery module is defined by the *electronic module*, which is mounted to the terminal module by a sliding mechanism. With an error the defective electronic module may be exchanged for a functional module with standing installation. At the front side there are LEDs for status indication. For simple wiring each module shows corresponding connection information at the front and at the side.


**16x periphery modules**

Each 16x periphery module consists of an *electronic unit* and a *terminal block*.



- 1 Electronic unit
- 2 Terminal block




**Electronic unit**

The functionality of a 16x periphery module is defined via the terminal block, which is connected to the *electronic unit* via a secure flap mechanism. In the case of an error you can exchange the defective electronic unit for a functional unit with standing wiring. At the front side there are LEDs for status indication. For easy wiring each electronic unit shows corresponding connection information at the side. The electronic unit provides the slot for the terminal block for the wiring and contains the backplane bus with power supply for the electronic and the connection to the DC 24V power section supply. Additionally the electronic unit has a locking system for fixing it at a mounting rail. By means of this locking system your system may be assembled outside of your switchgear cabinet to be later mounted there as whole system.

**Terminal block**

The *terminal block* provides the electrical interface for the signalling and supplies lines of the module. When mounting the terminal block, it is attached to the bottom of the electronic unit and turned towards the electronic unit until it clicks into place. With the wiring a "push-in" spring-clip technique is used. This allows a quick and easy connection of your signal and supply lines. The clamping off takes place by means of a screwdriver.

**Power module**


In the System SLIO the power supply is established by power modules. These are either integrated to the head module or may be installed between the periphery modules. Depending on the power module isolated areas of the DC 24V power section supply may be defined respectively the electronic power supply may be extended with 2A. For better recognition the colour of the power modules are contrasting to the periphery modules.

**2.2.3 Accessories****Shield bus carrier**


*Please note that a shield bus carrier cannot be mounted on a 16x periphery module!*



The shield bus carrier (order no.: 000-0AB00) serves to carry the shield bus (10mm x 3mm) to connect cable shields. Shield bus carriers, shield bus and shield fixings are not in the scope of delivery. They are only available as accessories. The shield bus carrier is mounted underneath the terminal of the terminal module. With a flat mounting rail for adaptation to a flat mounting rail you may remove the spacer of the shield bus carrier.



**Bus cover**



With each head module, to protect the backplane bus connectors, there is a mounted bus cover in the scope of delivery. You have to remove the bus cover of the head module before mounting a System SLIO module. For the protection of the backplane bus connector you always have to mount the bus cover at the last module of your system again. The bus cover has the order no. 000-0AA00.

**Coding pins**




*Please note that a coding pin cannot be installed on a 16x periphery module! Here you have to make sure that the associated terminal block is plugged again when the electronics unit is replaced.*

There is the possibility to fix the assignment of electronic and terminal module. Here coding pins (order number 000-0AC00) can be used. The coding pin consists of a coding jack and a coding plug. By combining electronic and terminal module with coding pin, the coding jack remains in the electronic module and the coding plug in the terminal module. This ensures that after replacing the electronic module just another electronic module can be plugged with the same encoding.

### 2.2.4 Hardware revision

#### Hardware revision on the front

- The hardware revision is printed on every System SLIO module.
- Since a System SLIO 8x peripheral module consists of a terminal and electronic module, you will find a hardware revision printed on each of them.
- Authoritative for the hardware revision of a System SLIO module is the hardware revision of the electronic module. This is located under the labeling strip of the corresponding electronic module.
- Depending on the module type, there are the following 2 variants e.g. to indicate hardware revision 1:
  - Current modules have a 1 on the front.
  - With earlier modules, the 1 is marked with 'X' on a number grid.



#### Hardware revision via web server

On the CPUs and some bus couplers, you can check the hardware revision 'HW Revision' via the integrated web server.

### 2.3 Dimensions


#### CPU 01xC

All dimensions are in mm.




Dimensions


CPU 01x






Bus coupler and line extension slave



Line extension master



**8x periphery module****Electronic module****16x periphery module**

## 2.4 Mounting 8x periphery modules




### CAUTION!


#### Requirements for UL compliance use

- Use for power supply exclusively SELV/PELV power supplies.
- The System SLIO must be installed and operated in a housing according to IEC 61010-1 9.3.2 c).

There is a locking lever at the top side of the module. For mounting and demounting this locking lever is to be turned upwards until this engages. For mounting place the module to the module installed before and push the module to the mounting rail guided by the strips at the upper and lower side of the module. The module is fixed to the mounting rail by pushing downward the locking lever. The modules may either separately be mounted to the mounting rail or as block. Here is to be considered that each locking lever is opened. The modules are each installed on a mounting rail. The electronic and power section supply are connected via the backplane bus. Up to 64 modules may be mounted. Please consider here that the sum current of the electronic power supply does not exceed the maximum value of 3A. By means of the power module 007-1AB10 the current of the electronic power supply may be expanded accordingly.




### Terminal and electronic module



Each periphery module consists of a *terminal* and an *electronic module*.

- 1 Terminal module
- 2 Electronic module


For the exchange of a electronic module, the electronic module may be pulled forward after pressing the unlocking lever at the lower side of the module. For installation plug the electronic module guided by the strips at the lower side until this engages audible to the terminal module.



## Coding



There is the possibility to fix the assignment of electronic and terminal module. Here coding pins (order number 000-0AC00) can be used. The coding pin consists of a coding jack and a coding plug. By combining electronic and terminal module with coding pin, the coding jack remains in the electronic module and the coding plug in the terminal module. This ensures that after replacing the electronics module just another electronic module can be plugged with the same encoding.



Each electronic module has on its back 2 coding sockets for coding jacks. Due to the characteristics, with the coding jack 6 different positions can be plugged, each. Thus there are 36 possible combinations for coding with the use of both coding sockets.


1. ➤ Plug, according to your coding, 2 coding jacks in the coding sockets of your electronic module until they lock
2. ➤ Now plug the according coding plugs into the coding jacks.
3. ➤ To fix the coding put both the electronic and terminal module together until they lock

**CAUTION!**



Please consider that when replacing an already coded electronic module, this is always be replaced by an electronic module with the same coding.

Even with an existing coding on the terminal module, you can plug an electronic module without coding. The user is responsible for the correct usage of the coding pins. Yaskawa assumes no liability for incorrectly attached electronic modules or for damages which arise due to incorrect coding!

**Mounting periphery modules**




1. ➤ Mount the mounting rail! Please consider that a clearance from the middle of the mounting rail of at least 80mm above and 60mm below, respectively 80mm by deployment of shield bus carriers, exist.
2. ➤ Mount your head module such as CPU or field bus coupler.
3. ➤ Before mounting the periphery modules you have to remove the bus cover at the right side of the head module by pulling it forward. Keep the cover for later mounting.



4. ➤ For mounting turn the locking lever of the module upwards until it engages.
5. ➤ For mounting place the module to the module installed before and push the module to the mounting rail guided by the strips at the upper and lower side of the module.
6. ➤ Turn the locking lever of the periphery module downward, again.





7. After mounting the whole system, to protect the backplane bus connectors at the last module you have to mount the bus cover, now. If the last module is a clamp module, for adaptation the upper part of the bus cover is to be removed.

## 2.5 Mounting 16x peripheral modules




### CAUTION!

#### Requirements for UL compliance use

- Use for power supply exclusively SELV/PELV power supplies.
- The System SLIO must be installed and operated in a housing according to IEC 61010-1 9.3.2 c).


There is a locking lever at the top side of the module. For mounting and demounting this locking lever is to be turned upwards until this engages. For mounting place the module to the module installed before and push the module to the mounting rail guided by the strips at the upper and lower side of the module. The module is fixed to the mounting rail by pushing downward the locking lever. The modules may either separately be mounted to the mounting rail or as block. Here is to be considered that each locking lever is opened. The modules are each installed on a mounting rail. The electronic and power section supply are connected via the backplane bus. Up to 64 modules may be mounted. Please consider here that the sum current of the electronic power supply does not exceed the maximum value of 3A. By means of the power module 007-1AB10 the current of the electronic power supply may be expanded accordingly.



Mounting 16x periphery modules


**Electronic unit and terminal block**

Each 16x periphery module consists of an *electronic unit* and a *terminal block*.




- 1 Electronic unit
- 2 Terminal block



To replace an electronic unit, you can push down and pull off the terminal block after releasing the lock. To mount the terminal block, place it horizontally on the lower side of the electronic unit and push it towards the electronic unit until it clicks into place.






**Mounting periphery module**



1. ➤ Mount the mounting rail! Please consider that a clearance from the middle of the mounting rail of at least 80mm above and 80mm below exist.
2. ➤ Mount your head module such as CPU or field bus coupler.
3. ➤ Before mounting the periphery modules you have to remove the bus cover at the right side of the head module by pulling it forward. Keep the cover for later mounting.



4. For mounting turn the locking lever of the module upwards until it engages.
5. For mounting place the module to the module installed before and push the module to the mounting rail guided by the strips at the upper and lower side of the module.
6. Turn the locking lever of the peripheral module downward, again.



7. After mounting the whole system, to protect the backplane bus connectors at the last module you have to mount the bus cover, now. If the last module is a clamp module, for adaptation the upper part of the bus cover is to be removed.

## 2.6 Wiring 8x peripheral modules

### Terminal module terminals




#### CAUTION!

#### Do not connect hazardous voltages!

If this is not explicitly stated in the corresponding module description, hazardous voltages are not allowed to be connected to the corresponding terminal module!


- With wiring the terminal modules, terminals with spring clamp technology are used for wiring. The spring clamp technology allows quick and easy connection of your signal and supply lines. In contrast to screw terminal connections this type of connection is vibration proof.

**Data**





$U_{max}$  240V AC / 30V DC  
 $I_{max}$  10A  
 Cross section 0.08 ... 1.5mm<sup>2</sup> (AWG 28 ... 16)  
 Stripping length 10mm

**Wiring procedure**




- 1 Pin number at the connector
- 2 Opening for screwdriver
- 3 Connection hole for wire



1. Insert a suited screwdriver at an angle into the square opening as shown. Press and hold the screwdriver in the opposite direction to open the contact spring.
2. Insert the stripped end of wire into the round opening. You can use wires with a cross section of 0.08mm<sup>2</sup> up to 1.5mm<sup>2</sup>
3. By removing the screwdriver, the wire is securely fixed via the spring contact to the terminal.


**Shield attachment**



- 1 Shield bus carrier
- 2 Shield bus (10mm x 3mm)
- 3 Shield clamp
- 4 Cable shield

To attach the shield the mounting of shield bus carriers are necessary. The shield bus carrier (available as accessory) serves to carry the shield bus to connect cable shields.

1. Each System SLIO 8x periphery module has a carrier hole for the shield bus carrier. Push the shield bus carrier, until they engage into the module. With a flat mounting rail for adaptation to a flat mounting rail you may remove the spacer of the shield bus carrier.
2. Put your shield bus into the shield bus carrier.



3. Attach the cables with the accordingly stripped cable screen and fix it by the shield clamp with the shield bus.

## 2.7 Wiring 16x periphery modules

### Terminal block connectors




#### CAUTION!

#### Do not connect hazardous voltages!

If this is not explicitly stated in the corresponding module description, hazardous voltages are not allowed to be connected to the corresponding terminal block!

- The 16x periphery module has a removable terminal block for wiring.
- With the wiring of the terminal block a "push-in" spring-clip technique is used. This allows a quick and easy connection of your signal and supply lines.
- The clamping off takes place by means of a screwdriver.
- Please use copper wire only!

### Data




$U_{max}$	30V DC
$I_{max}$	10A
Cross section solid wire	0.25 ... 0.75mm <sup>2</sup>
Cross section with ferrule	0.14 ... 0.75mm <sup>2</sup>
Wire type	CU
AWG	24 ... 16
Stripping length	10mm

### Wiring procedure



- 1 Release area
- 2 Connection hole for wire


**Insert wire**



The wiring happens without a tool.

1. Determine according to the casing labelling the connection position.
2. Insert through the round connection hole of the according contact your prepared wire until it stops, so that it is fixed.
  - ⇒ By pushing the contact spring opens, thus ensuring the necessary contact pressure.

**Remove wire**



The wire is to be removed by means of a screwdriver with 2.5mm blade width.


1. Press with your screwdriver vertically at the release button.
  - ⇒ The contact spring releases the wire.
2. Pull the wire from the round hole.

**2.8 Wiring power modules**

**Terminal module terminals**


Power modules are either integrated to the head module or may be installed between the periphery modules. With power modules, terminals with spring clamp technology are used for wiring. The spring clamp technology allows quick and easy connection of your signal and supply lines. In contrast to screw terminal connections this type of connection is vibration proof.

**Data**





$U_{max}$	30V DC
$I_{max}$	10A
Cross section	0.08 ... 1.5mm <sup>2</sup> (AWG 28 ... 16)
Stripping length	10mm

**Wiring procedure**




- 1 Pin number at the connector
- 2 Opening for screwdriver
- 3 Connection hole for wire



- 1. Insert a suited screwdriver at an angle into the square opening as shown. Press and hold the screwdriver in the opposite direction to open the contact spring.
- 2. Insert the stripped end of wire into the round opening. You can use wires with a cross section of 0.08mm<sup>2</sup> up to 1.5mm<sup>2</sup>
- 3. By removing the screwdriver, the wire is securely fixed via the spring contact to the terminal.


**Standard wiring**



- (1) DC 24V for power section supply I/O area (max. 10A)
- (2) DC 24V for electronic power supply bus coupler and I/O area

Wiring power modules

**PM - Power module**



For wires with a core cross-section of 0.08mm<sup>2</sup> up to 1.5mm<sup>2</sup>.

Pos.	Function	Type	Description
1	---	---	not connected
2	DC 24V	I	DC 24V for power section supply
3	0V	I	GND for power section supply
4	Sys DC 24V	I	DC 24V for electronic section supply
5	---	---	not connected
6	DC 24V	I	DC 24V for power section supply
7	0V	I	GND for power section supply
8	Sys 0V	I	GND for electronic section supply

I: Input



**CAUTION!**

Since the power section supply is not internally protected, it is to be externally protected with a fuse, which corresponds to the maximum current. This means max. 10A is to be protected by a 10A fuse (fast) respectively by a line circuit breaker 10A characteristics Z!



*The electronic power section supply is internally protected against higher voltage by fuse. The fuse is within the power module. If the fuse releases, its electronic module must be exchanged!*

**Fusing**

- The power section supply is to be externally protected with a fuse, which corresponds to the maximum current. This means max. 10A is to be protected with a 10A fuse (fast) respectively by a line circuit breaker 10A characteristics Z!
- It is recommended to externally protect the electronic power supply for head modules and I/O area with a 2A fuse (fast) respectively by a line circuit breaker 2A characteristics Z.
- The electronic power supply for the I/O area of the power module 007-1AB10 should also be externally protected with a 1A fuse (fast) respectively by a line circuit breaker 1A characteristics Z.

**State of the electronic power supply via LEDs**


After PowerON of the System SLIO the LEDs RUN respectively MF get on so far as the sum current does not exceed 3A. With a sum current greater than 3A the LEDs may not be activated. Here the power module with the order number 007-1AB10 is to be placed between the peripheral modules.




**Deployment of the power modules**

- If the 10A for the power section supply is no longer sufficient, you may use the power module with the order number 007-1AB00. So you have also the possibility to define isolated groups.
- The power module with the order number 007-1AB10 is to be used if the 3A for the electronic power supply at the backplane bus is no longer sufficient. Additionally you get an isolated group for the DC 24V power section supply with max. 4A.
- By placing the power module 007-1AB10 at the following backplane bus modules may be placed with a sum current of max. 2A. Afterwards a power module is to be placed again. To secure the power supply, the power modules may be mixed used.

**Power module 007-1AB00**




**Power module 007-1AB10**



- (1) DC 24V for power section supply I/O area (max. 10A)
- (2) DC 24V for electronic power supply bus coupler and I/O area
- (3) DC 24V for power section supply I/O area (max. 4A)
- (4) DC 24V for electronic power supply I/O area


Shield attachment



- 1 Shield bus carrier
- 2 Shield bus (10mm x 3mm)
- 3 Shield clamp
- 4 Cable shield

To attach the shield the mounting of shield bus carriers are necessary. The shield bus carrier (available as accessory) serves to carry the shield bus to connect cable shields.

1. Each System SLIO 8x peripheral module has a carrier hole for the shield bus carrier. Push the shield bus carrier, until they engage into the module. With a flat mounting rail for adaptation to a flat mounting rail you may remove the spacer of the shield bus carrier.
2. Put your shield bus into the shield bus carrier.




3. Attach the cables with the accordingly stripped cable screen and fix it by the shield clamp with the shield bus.

## 2.9 Demounting 8x periphery modules

### Proceeding

#### Exchange of an electronic module

1. ➤ Power-off your system.



2. ➤ For the exchange of a electronic module, the electronic module may be pulled forward after pressing the unlocking lever at the lower side of the module.
3. ➤ For installation plug the new electronic module guided by the strips at the lower side until this engages to the terminal module.
  - ⇒ Now you can bring your system back into operation.




#### Easy Maintenance

'Easy Maintenance' means the support for adding and removing electronic modules during operation without having to restart the system. If this is supported by your head module, you will find more detailed information on this in the "Deployment" chapter. ↪ Chap. 2.11 'Easy Maintenance' page 37

Demounting 8x periphery modules


**Exchange of a periphery module**




1. ➤ Power-off your system.
2. ➤ Remove if exists the wiring of the module.
3. ➤

**i** For demounting and exchange of a (head) module or a group of modules, due to mounting reasons you always have to remove the electronic module right beside. After mounting it may be plugged again.


Press the unlocking lever at the lower side of the just mounted right module and pull it forward.




4. ➤ Turn the locking lever of the module to be exchanged upwards.



5. ➤ Pull the module.
6. ➤ For mounting turn the locking lever of the module to be mounted upwards.








7. ➤ To mount the module put it to the gap between the both modules and push it, guided by the stripes at both sides, to the mounting rail.
8. ➤ Turn the locking lever downward, again.



9. ➤ Plug again the electronic module, which you have removed before.
10. ➤ Wire your module.
  - ⇒ Now you can bring your system back into operation.

### Exchange of a module group



1. ➤ Power-off your system.
2. ➤ Remove if exists the wiring of the module group.
3. ➤



*For demounting and exchange of a (head) module or a group of modules, due to mounting reasons you always have to remove the electronic module right beside. After mounting it may be plugged again.*

Press the unlocking lever at the lower side of the just mounted right module near the module group and pull it forward.

4. ➤ Turn all the locking lever of the module group to be exchanged upwards.
5. ➤ Pull the module group forward.
6. ➤ For mounting turn all the locking lever of the module group to be mounted upwards.

7. ➤ To mount the module group put it to the gap between the both modules and push it, guided by the stripes at both sides, to the mounting rail.
8. ➤ Turn all the locking lever downward, again.

9. ➤ Plug again the electronic module, which you have removed before.
10. ➤ Wire your module group.
  - ⇒ Now you can bring your system back into operation.

## 2.10 Demounting 16x periphery modules


### Proceeding

#### Exchange of an electronic unit


1. ➤ Power-off your system.
2. ➤ To replace an electronic unit, you can push down and pull off the terminal block after releasing the lock.

To mount the terminal block, place it horizontally on the lower side of the electronic unit and push it towards the electronic unit until it clicks into place.

⇒ Now you can bring your system back into operation.



#### Exchange of a 16x periphery module




1. ➤ Power-off your system.
2. ➤ Remove if exists the wiring of the module respectively the wired terminal block.
3. ➤




*In contrast to 8x periphery modules, you can directly demount and mount 16x periphery modules.*


Turn the locking lever of the module to be exchanged upwards.



4. ➤ Pull the module.
5. ➤ For mounting turn the locking lever of the module to be mounted upwards.




6. ➤ To mount the module put it to the gap between the both modules and push it, guided by the stripes at both sides, to the mounting rail.



7. ➤ Turn the locking lever downward, again.
8. ➤ Wire your module respectively plug the wired terminal block again.
  - ⇒ Now you can bring your system back into operation.

**Exchange of a module group**




1. ➤ Power-off your system.
2. ➤ Remove if exists the wiring of the module group respectively the wired terminal blocks.
3. ➤


**i** *In contrast to 8x periphery modules, you can directly demount and mount 16x periphery modules.*

Turn all the locking lever of the module group to be exchanged upwards.


Demounting 16x periphery modules



4. ➤ Pull the module group forward.
5. ➤ For mounting turn all the locking lever of the module group to be mounted upwards.



6. ➤ To mount the module group put it to the gap between the both modules and push it, guided by the stripes at both sides, to the mounting rail.



7. ➤ Turn all the locking lever downward, again.
8. ➤ Wire your module group respectively plug the wired terminal blocks again.
  - ⇒ Now you can bring your system back into operation.



## 2.11 Easy Maintenance

### Overview

*Easy Maintenance* means the support for adding and removing an electronic module during operation without having to restart the system. Here the following behavior is shown by the example of a CPU:

- Electronic module is removed
  - The CPU detects a module failure on the backplane bus.
  - Diagnostic message ‘*System SLIO bus failure*’ (0x39D0) is triggered.
  - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
  - The SF LED of the CPU lights up.
  - The I/O data of all modules become invalid.
- Identical electronic module is plugged
  - The CPU detects the module return on the backplane bus.
  - The SF-LED of the CPU gets off.
  - All RUN LEDs on the modules get on and the MF LEDs get off.
  - Diagnostic message ‘*System SLIO bus recovery*’ (0x38D0) is triggered.
  - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
  - The I/O data of all modules become valid again.
- Wrong electronic module is plugged
  - The CPU detects the wrong module.
  - Diagnostic message ‘*System SLIO bus recovery, but expected configuration does not match actual configuration*’ (0x38D1) is triggered.
  - The SF LED of the CPU remains on.
  - The MF LED of the wrong module flashes.
  - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
  - With the exception of the wrong module, the I/O data of all modules become valid again.



#### CAUTION!

Please note that only electronic modules may be exchanged during operation! Replacing an 8x or 16x periphery module during operation can damage the module and the system!



*Please note that the CPU switches to STOP, if there is no OB 86 configured when adding or removing System SLIO modules!*


## 2.12 Trouble shooting - LEDs

### General

Each module has the LEDs RUN and MF on its front side. Errors or incorrect modules may be located by means of these LEDs.

In the following illustrations flashing LEDs are marked by ☼.

### Sum current of the electronic power supply exceeded




**Behaviour:** After PowerON the RUN LED of each module is off and the MF LED of each module is sporadically on.

**Reason:** The maximum current for the electronic power supply is exceeded.

**Remedy:** As soon as the sum current of the electronic power supply is exceeded, always place the power module 007-1AB10. ↪ Chap. 2.8 'Wiring power modules' page 26

### Error in configuration




**Behaviour:** After PowerON the MF LED of one module respectively more modules flashes. The RUN LED remains off.

**Reason:** At this position a module is placed, which does not correspond to the configured module.

**Remedy:** Match configuration and hardware structure.

### Module failure



**Behaviour:** After PowerON all of the RUN LEDs up to the defective module are flashing. With all following modules the MF LED is on and the RUN LED is off.

**Reason:** The module on the right of the flashing modules is defective.

**Remedy:** Replace the defective module.

## 2.13 Industrial security and installation guidelines

### 2.13.1 Industrial security in information technology

#### Latest version

This chapter can also be found as a guide '*Industrial IT Security*' at [www.yaskawa.eu.com](http://www.yaskawa.eu.com)

#### Hazards

The topic of data security and access protection has become increasingly important in the industrial environment. The increased networking of entire industrial systems to the network levels within the company together with the functions of remote maintenance have all served to increase vulnerability. Hazards can arise from:

- Internal manipulation such as technical errors, operating and program errors and deliberate program or data manipulation.
- External manipulation such as software viruses, worms and Trojans.
- Human carelessness such as password phishing.

#### Precautions

The most important precautions to prevent manipulation and loss of data security in the industrial environment are:

- Encrypting the data traffic by means of certificates.
- Filtering and inspection of the traffic by means of VPN - "Virtual Private Networks".
- Identification of the user by "Authentication" via safe channels.
- Segmenting in protected automation cells, so that only devices in the same group can exchange data.
- Deactivation of unnecessary hardware and software.

#### Further Information

You can find more information about the measures on the following websites:

- Federal Office for Information Technology [www.bsi.bund.de](http://www.bsi.bund.de)
- Cybersecurity & Infrastructure Security Agency [us-cert.cisa.gov](http://us-cert.cisa.gov)
- VDI / VDE Society for Measurement and Automation Technology [www.vdi.de](http://www.vdi.de)

### 2.13.1.1 Protection of hardware and applications

#### Precautions

- Do not integrate any components or systems into public networks.
  - Use VPN "Virtual Private Networks" for use in public networks. This allows you to control and filter the data traffic accordingly.
- Always keep your system up-to-date.
  - Always use the latest firmware version for all devices.
  - Update your user software regularly.
- Protect your systems with a firewall.
  - The firewall protects your infrastructure internally and externally.
  - This allows you to segment your network and isolate entire areas.
- Secure access to your plants via user accounts.
  - If possible, use a central user management system.
  - Create a user account for each user for whom authorization is essential.
  - Always keep user accounts up-to-date and deactivate unused user accounts.
- Secure access to your plants via secure passwords.
  - Change the password of a standard login after the first start.
  - Use strong passwords consisting of upper/lower case, numbers and special characters. The use of a password generator or manager is recommended.
  - Change the passwords according to the rules and guidelines that apply to your application.
- Deactivate inactive communication ports respectively protocols.
  - Only the communication ports that are used for communication should be activated.
  - Only the communication protocols that are used for communication should be activated.
- Consider possible defence strategies when planning and securing the system.
  - The isolation of components alone is not sufficient for comprehensive protection. An overall concept is to be drawn up here, which also provides defensive measures in the event of a cyber attack.
  - Periodically carry out threat assessments. Among others, a comparison is made here between the protective measures taken and those required.
- Limit the use of external storage media.
  - Via external storage media such as USB memory sticks or SD memory cards, malware can get directly into a system while bypassing a firewall.
  - External storage media or their slots must be protected against unauthorized physical access, e.g. by using a lockable control cabinet.
  - Make sure that only authorized persons have access.
  - When disposing of storage media, make sure that they are safely destroyed.
- Use secure access paths such as HTTPS or VPN for remote access to your plant.
- Enable security-related event logging in accordance with the applicable security policy and legal requirements for data protection.

### 2.13.1.2 Protection of PC-based software

#### Precautions

Since PC-based software is used for programming, configuration and monitoring, it can also be used to manipulate entire systems or individual components. Particular caution is required here!

- Use user accounts on your PC systems.
  - If possible, use a central user management system.
  - Create a user account for each user for whom authorization is essential.
  - Always keep user accounts up-to-date and deactivate unused user accounts.
- Protect your PC systems with secure passwords.
  - Change the password of a standard login after the first start.
  - Use strong passwords consisting of upper/lower case, numbers and special characters. The use of a password generator or manager is recommended.
  - Change the passwords according to the rules and guidelines that apply to your application.
- Enable security-related event logging in accordance with the applicable security policy and legal requirements for data protection.
- Protect your PC systems by security software.
  - Install virus scanners on your PC systems to identify viruses, trojans and other malware.
  - Install software that can detect phishing attacks and actively prevent them.
- Always keep your software up-to-date.
  - Update your operating system regularly.
  - Update your software regularly.
- Make regular backups and store the media at a safe place.
- Regularly restart your PC systems. Only boot from storage media that are protected against manipulation.
- Use encryption systems on your storage media.
- Perform security assessments regularly to reduce the risk of manipulation.
- Use only data and software from approved sources.
- Uninstall software which is not used.
- Disable unused services.
- Activate a password-protected screen lock on your PC systems.
- Always lock your PC systems as soon as you leave your PC workstation.
- Do not click any links that come from unknown sources. If necessary ask, e.g. on e-mails.
- Use secure access paths such as HTTPS or VPN for remote access to your PC system.

### 2.13.2 Installation guidelines

#### General

The installation guidelines contain information about the interference free deployment of a PLC system. There is the description of the ways, interference may occur in your PLC, how you can make sure the electromagnetic compatibility (EMC), and how you manage the isolation.

#### What does EMC mean?

Electromagnetic compatibility (EMC) means the ability of an electrical device, to function error free in an electromagnetic environment without being interfered respectively without interfering the environment.

The components are developed for the deployment in industrial environments and meets high demands on the EMC. Nevertheless you should project an EMC planning before installing the components and take conceivable interference causes into account.

**Possible interference causes**

Electromagnetic interferences may interfere your control via different ways:

- Electromagnetic fields (RF coupling)
- Magnetic fields with power frequency
- Bus system
- Power supply
- Protected earth conductor

Depending on the spreading medium (lead bound or lead free) and the distance to the interference cause, interferences to your control occur by means of different coupling mechanisms.

There are:

- galvanic coupling
- capacitive coupling
- inductive coupling
- radiant coupling

**Basic rules for EMC**

In the most times it is enough to take care of some elementary rules to guarantee the EMC. Please regard the following basic rules when installing your PLC.

- Take care of a correct area-wide grounding of the inactive metal parts when installing your components.
  - Install a central connection between the ground and the protected earth conductor system.
  - Connect all inactive metal extensive and impedance-low.
  - Please try not to use aluminium parts. Aluminium is easily oxidizing and is therefore less suitable for grounding.
- When cabling, take care of the correct line routing.
  - Organize your cabling in line groups (high voltage, current supply, signal and data lines).
  - Always lay your high voltage lines and signal respectively data lines in separate channels or bundles.
  - Route the signal and data lines as near as possible beside ground areas (e.g. suspension bars, metal rails, tin cabinet).
- Proof the correct fixing of the lead isolation.
  - Data lines must be shielded.
  - Analog lines must be shielded. When transmitting signals with small amplitudes the one sided laying of the isolation may be favourable.
  - Cables for frequency inverters, servo and stepper motors must be shielded.
  - Lay the line isolation extensively on an isolation/protected earth conductor rail directly after the cabinet entry and fix the isolation with cable clamps.
  - Make sure that the isolation/protected earth conductor rail is connected impedance-low with the cabinet.
  - Use metallic or metallised plug cases for isolated data lines.
- In special use cases you should appoint special EMC actions.
  - Consider to wire all inductivities with erase links.
  - Please consider luminescent lamps can influence signal lines.
- Create a homogeneous reference potential and ground all electrical operating supplies when possible.
  - Please take care for the targeted employment of the grounding actions. The grounding of the PLC serves for protection and functionality activity.
  - Connect installation parts and cabinets with your PLC in star topology with the isolation/protected earth conductor system. So you avoid ground loops.
  - If there are potential differences between installation parts and cabinets, lay sufficiently dimensioned potential compensation lines.

**Isolation of conductors**

Electrical, magnetically and electromagnetic interference fields are weakened by means of an isolation, one talks of absorption. Via the isolation rail, that is connected conductive with the rack, interference currents are shunt via cable isolation to the ground. Here you have to make sure, that the connection to the protected earth conductor is impedance-low, because otherwise the interference currents may appear as interference cause.

When isolating cables you have to regard the following:

- If possible, use only cables with isolation tangle.
- The hiding power of the isolation should be higher than 80%.
- Normally you should always lay the isolation of cables on both sides. Only by means of the both-sided connection of the isolation you achieve high quality interference suppression in the higher frequency area. Only as exception you may also lay the isolation one-sided. Then you only achieve the absorption of the lower frequencies. A one-sided isolation connection may be convenient, if:
  - the conduction of a potential compensating line is not possible.
  - analog signals (some mV respectively  $\mu\text{A}$ ) are transferred.
  - foil isolations (static isolations) are used.
- With data lines always use metallic or metallised plugs for serial couplings. Fix the isolation of the data line at the plug rack. Do not lay the isolation on the PIN 1 of the plug bar!
- At stationary operation it is convenient to strip the insulated cable interruption free and lay it on the isolation/protected earth conductor line.
- To fix the isolation tangles use cable clamps out of metal. The clamps must clasp the isolation extensively and have well contact.
- Lay the isolation on an isolation rail directly after the entry of the cable in the cabinet. Lead the isolation further on to your PLC and don't lay it on there again!

**CAUTION!****Please regard at installation!**

At potential differences between the grounding points, there may be a compensation current via the isolation connected at both sides.

Remedy: Potential compensation line

**2.14 General data for the System SLIO****Conformity and approval**

Conformity		
CE	2014/35/EU	Low-voltage directive
	2014/30/EU	EMC directive
Approval		
UL	-	Refer to Technical data
Others		
RoHS	2011/65/EU	Restriction of the use of certain hazardous substances in electrical and electronic equipment

General data for the System SLIO

**Protection of persons and device protection**

Type of protection	-	IP20
Electrical isolation		
to the field bus	-	electrically isolated
to the process level	-	electrically isolated
Insulation resistance	-	-
Insulation voltage to reference earth		
Inputs / outputs	-	AC / DC 50V, test voltage AC 500V
Protective measures	-	against short circuit

**Environmental conditions to EN 61131-2**

Climatic		
Storage / transport	EN 60068-2-14	-25...+70°C
Operation		
Horizontal installation hanging	EN 61131-2	0...+60°C
Horizontal installation lying	EN 61131-2	0...+55°C
Vertical installation	EN 61131-2	0...+50°C
Air humidity	EN 60068-2-30	RH1 (without condensation, rel. humidity 10...95%)
Pollution	EN 61131-2	Degree of pollution 2
Installation altitude max.	-	2000m
Mechanical		
Oscillation	EN 60068-2-6	1g, 9Hz ... 150Hz
Shock	EN 60068-2-27	15g, 11ms

**Mounting conditions**

Mounting place	-	In the control cabinet
Mounting position	-	Horizontal and vertical



EMC	Standard	Comment	
Emitted interference	EN 61000-6-4	Class A (Industrial area)	
Noise immunity zone B	EN 61000-6-2	Industrial area	
		EN 61000-4-2	ESD 8kV at air discharge (degree of severity 3), 4kV at contact discharge (degree of severity 2)
		EN 61000-4-3	HF field immunity (casing) 80MHz ... 1000MHz, 10V/m, 80% AM (1kHz) 1.4GHz ... 2.0GHz, 3V/m, 80% AM (1kHz) 2GHz ... 2.7GHz, 1V/m, 80% AM (1kHz)
		EN 61000-4-6	HF conducted 150kHz ... 80MHz, 10V, 80% AM (1kHz)
		EN 61000-4-4	Burst, degree of severity 3
	EN 61000-4-5	Surge, degree of severity 3 <sup>1</sup>	

1) Due to the high-energetic single pulses with Surge an appropriate external protective circuit with lightning protection elements like conductors for lightning and overvoltage is necessary.

### 2.14.1 Use in difficult operating conditions



*Without additional protective measures, the products must not be used in locations with difficult operating conditions; e.g. due to:*

- *dust generation*
- *chemically active substances (corrosive vapors or gases)*
- *strong electric or magnetic fields*


## 3 Hardware description

### 3.1 Properties

#### 054-1CB00

The FM 054-1CB00 is a motion module for controlling 2 axis drive with DC motor. It can be used for point-to-point positioning and for complex drive profiles with the highest demands on precision, dynamics and speed.

- DC motor module for controlling 2 axis
- 4 inputs/outputs DC 24V, which can be used as encoder inputs
- PWM clock speed 32kHz



#### Compatibility list


An overview of CPU and bus coupler, which support the 054-1CB00, can be found at [www.yaskawa.eu.com](http://www.yaskawa.eu.com) at the download area of the System SLIO manuals.

#### Ordering data

Type	Order number	Description
FM 054 2xDC	054-1CB00	System SLIO 2x DC motor module, DC 24V, 1.5A 2 channels with feedback, 4 inputs/outputs DC 24V


### 3.2 Structure

#### 054-1CB00



- 1 Locking lever terminal module
- 2 Labeling strip
- 3 Backplane bus
- 4 LED status indication
- 5 DC 24V power section supply
- 6 Electronic module
- 7 Terminal module
- 8 Locking lever electronic module
- 9 Terminal


#### Connections




**CAUTION!**  
**Danger of injury from electrical shock and damage to the unit!**  
 Put the System SLIO in a safe, powered down state before starting installation, disassembly or wiring of the System SLIO modules!

You can use wires with a cross section of 0.08mm<sup>2</sup> up to 1.5mm<sup>2</sup>. For the connection lines the following requirements apply:

- For the digital I/O connection with DIO operation single lines can be used. In encoder mode, shielded cables are to be used.
- A motor must be connected via shielded lines.
- Generally, power and signal lines must be laid separately.



Structure



Pos.	Function	Type	Description
1	PA1	O	DC Motor 1 - connection 1
2	PA2	O	DC Motor 1 - connection 2
3	I/O1	I/O	Digital input/output 1
4	I/O3	I/O	Digital input/output 3
5	PB1	O	DC Motor 2 - connection 1
6	PB2	O	DC Motor 2 - connection 2
7	I/O2	I/O	Digital input/output 2
8	I/O4	I/O	Digital input/output 4

I: Input, O: Output




**Power supply**


The module is to be power supplied with the both DC 24V voltages power section supply I/O area and electronic power supply. When commissioning these may simultaneously or electronic power supply must be switched on first. When commissioning these may simultaneously or power section supply I/O area must be switched on first. ↗ 'Standard wiring' page 27

**Connecting an encoder**

There is the possibility to connect an encoder via I/O1 and I/O3 respectively via I/O2 and I/O4. Current values of position, velocity, acceleration and deceleration are calculated by the System SLIO motion module itself. If there is no more encoder connected, the unused digital in-/outputs are further free for usage.



Encoder mode: 24V HTL signal  
Phase A and B  
100 kHz  
4-fold evaluation










































Pos.	Function	Type	Description
3	I/O1	I	Encoder function drive 1
4	I/O3	I	Encoder function drive 1
7	I/O2	I	Encoder function drive 2
8	I/O4	I	Encoder function drive 2

I: Input, O: Output

↗ Chap. 4.9.2.2 'Encoder - deployment' page 93

## Status indication




RUN	MF	Description	
green 	red 		
		Bus communication is OK Module status is OK	
		Bus communication is OK Module status reports an error	
		Bus communication is not possible Module status reports an error	
		Error at bus power supply	
X		Error in configuration ↪ <i>Chap. 2.12 'Trouble shooting - LEDs' page 38</i>	
PWRA	green 		The state of drive 1 is beyond 'Switched on' and 'Operation enabled' ↪ <i>Chap. 4.4.2 'States' page 63</i>
			Drive 1 is in state 'Switched on'
			Drive 1 is in state 'Operation enabled'
PWRB	green 		The state of drive 2 is beyond 'Switched on' and 'Operation enabled' ↪ <i>Chap. 4.4.2 'States' page 63</i>
			Drive 2 is in state 'Switched on'
			Drive 2 is in state 'Operation enabled'
ERRA	red 		No error drive 1
			Warning drive 1: 0x80 in ↪ <i>'0x8100-02 - Status word' page 122</i>
			Error drive 1: 0x08 in ↪ <i>'0x8100-02 - Status word' page 122</i>
ERRB	red 		No error drive 2
			Warning drive 2: 0x80 in ↪ <i>'0x8100-02 - Status word' page 122</i>
			Error drive 2: 0x08 in ↪ <i>'0x8100-02 - Status word' page 122</i>
I/O1	green 		Digital input/output 1 has "0" signal
			Digital input/output 1 has "1" signal
I/O2	green 		Digital input/output 2 has "0" signal
			Digital input/output 2 has "1" signal
I/O3	green 		Digital input/output 3 has "0" signal
			Digital input/output 3 has "1" signal
I/O4	green 		Digital input/output 4 has "0" signal

Block diagram

RUN	MF	Description
		■ Digital input/output 4 has "1" signal
not relevant: X		

### 3.3 Block diagram

#### Structure



#### Voltages

- $U_{Sys}$  - DC 24V electronic section supply  
Power supply for electronic and back plane bus communication
- $U_{IN}$  - DC 24V power section supply  
Power supply for the I/O area  
Area: DC 20.4 ... 28.8V
- $U_D$  - DC 10V driver supply  
The power supply is built via  $U_{IN}$  via a DC-DC converter and enabled via the  $\mu$ -controller.
- $U_C$  - DC 3.3V  $\mu$ -controller supply  
The power supply is built via  $U_{IN}$  via a DC-DC converter.  
ON: Edge 0-1 at 16V from  $U_{IN}$   
OFF: Edge 1-0 at 14V from  $U_{IN}$
- $U_M$  - Motor power supply  
ON: Edge 0-1 at 19.2V from  $U_{IN}$   
OFF: Edge 1-0 at 18.5V from  $U_{IN}$

**Temperature monitoring**

The motion module has an internal temperature monitoring of the  $\mu$ -controller and the power stage. Via the object dictionary limit temperatures can be defined. If the temperature over or under runs the limit values, there is an error reaction of the motion module, which can be configured. ↪ '0x8780-02 - Temperature  $\mu$ -Controller actual value' page 151

**3.4 Technical data**

<b>Order no.</b>	<b>054-1CB00</b>
Type	FM 054
Module ID	0982 6800
<b>Current consumption/power loss</b>	
Current consumption from backplane bus	50 mA
Power loss	1 W
<b>Technical data digital inputs</b>	
Number of inputs	4
Cable length, shielded	1000 m
Cable length, unshielded	600 m
Rated load voltage	-
Current consumption from load voltage L+ (without load)	-
Rated value	DC 20.4...28.8 V
Input voltage for signal "0"	DC 0...5 V
Input voltage for signal "1"	DC 11...28.8 V
Input voltage hysteresis	-
Frequency range	-
Input resistance	-
Input current for signal "1"	3 mA
Connection of Two-Wire-BEROs possible	✓
Max. permissible BERO quiescent current	1.5 mA
Input delay of "0" to "1"	1.5 ms
Input delay of "1" to "0"	1.5 ms
Number of simultaneously utilizable inputs horizontal configuration	4
Number of simultaneously utilizable inputs vertical configuration	4
Input characteristic curve	IEC 61131-2, type 3
Initial data size	4 Bit
<b>Technical data digital outputs</b>	
Number of outputs	4
Cable length, shielded	1000 m

## Technical data

Order no.	054-1CB00
Cable length, unshielded	600 m
Rated load voltage	DC 20.4...28.8 V
Reverse polarity protection of rated load voltage	-
Current consumption from load voltage L+ (without load)	-
Output current at signal "1", rated value	500 mA
Output delay of "0" to "1"	1.5 ms
Output delay of "1" to "0"	1.5 ms
Minimum load current	-
Lamp load	10 W
Parallel switching of outputs for redundant control of a load	not possible
Parallel switching of outputs for increased power	not possible
Actuation of digital input	✓
Switching frequency with resistive load	max. 300 Hz
Switching frequency with inductive load	max. 0.5 Hz
Switching frequency on lamp load	max. 10 Hz
Internal limitation of inductive shut-off voltage	L+ (-45 V)
Short-circuit protection of output	yes, electronic
Trigger level	1 A
Number of operating cycle of relay outputs	-
Switching capacity of contacts	-
Output data size	-
<b>Status information, alarms, diagnostics</b>	
Status display	green LED per channel
Interrupts	yes, parameterizable
Process alarm	no
Diagnostic interrupt	yes, parameterizable
Diagnostic functions	yes
Diagnostics information read-out	possible
Supply voltage display	green LED
Group error display	red LED
Channel error display	red LED per channel
<b>Isolation</b>	
Between channels	-
Between channels of groups to	-
Between channels and backplane bus	✓
Insulation tested with	AC 500 V



<b>Order no.</b>	<b>054-1CB00</b>
<b>Technical data positioning module</b>	
Number of channels	2
Input voltage (rated value)	DC 24 V
Input voltage (permitted range)	DC 20.4...28.8 V
Motor current	1.5 A
Power stage	2x Full bridge PWM
Short-circuit protection	✓
Brake-Chopper required	-
PWM frequency	32 kHz
Pulse train frequency	-
Micro steps	-
Steps per rotation	-
Type of encoder	A/B phase 24V single ended
Encoder frequency	100 kHz
Encoder resolution	24 Bit
Control type	closed loop
Temperature sensor	✓
<b>Operating modes position functions</b>	
Homing via homing switch	✓
Positioning via torque	✓
Positioning without encoder	✓
Positioning with encoder	✓
Speed control	✓
Torque control	✓
<b>Housing</b>	
Material	PPE / PPE GF10
Mounting	Profile rail 35 mm
<b>Mechanical data</b>	
Dimensions (WxHxD)	12.9 mm x 109 mm x 76.5 mm
Net weight	65 g
Weight including accessories	65 g
Gross weight	79 g
<b>Environmental conditions</b>	
Operating temperature	0 °C to 60 °C
Storage temperature	-25 °C to 70 °C
<b>Certifications</b>	

---

Technical data

<b>Order no.</b>	<b>054-1CB00</b>
UL certification	yes
KC certification	in preparation

## 4 Deployment

### 4.1 Basics

#### Addressing

The System SLIO motion module provides its data, such as "Profiling target position" via an object dictionary. In this object dictionary the objects are organized and addressable a unique number consisting of *Index* and *Subindex*. The number is specified as follows:

0x	Index (hexadecimal)	-	Subindex (decimal)
Example: 0x8400-03			



*To improve the structure and for expansion at System SLIO Motion Module another object numbering (index-assignment) is used besides the standard CiA 402.*

#### Index area

By separating into index and subindex a grouping is possible. The individual areas are divided into groups of related objects. With the System SLIO motion module this object directory is structured as follows:

Index area	Content
0x1000 ... 0x6FFF	General data and system data
0x7000 ... 0x7FFF	Data of the digital input and output part
0x8000 ... 0x8FFF	Data drive 1
0x9000 ... 0x9FFF	Data drive 2



*Each object has a subindex 0. Calling an object with subindex 0, the number of available subindexes of the corresponding object is returned.*

#### Accessing the object dictionary

You have the following options for accessing the objects in the object dictionary:

- Access via acyclic channel
  - Any access to the object dictionary is acknowledged by the motion module.
  - ↪ *Chap. 4.12 'Acyclic channel' page 98*
- Access via I/O area
  - The main objects are mapped in the I/O area.
  - The mapping cannot be changed.
  - ↪ *Chap. 4.11 'In-/Output area' page 95*



*Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.*

**Overview**

The motion module uses 60byte input and 60byte output data.

Head module	Backplane bus	Motion module	
CPU respectively bus coupler	→	Process data	Acyclic channel
	←	60byte	



*The data exchange with the motion module must be consistent across the 60 bytes! It is recommended to control it via the process image.*


**4.1.1 DC motor module**

The FM 054-1CB00 integrates a compact motion control solution for direct control of two DC motors in a very compact design. DC motors are easy to control because the speed is proportional to the voltage. The controlling of the current happens by means of PWM with a clock speed of 32kHz. By connecting an encoder per drive and the integration into the control circuit, the implementation of simple axes is possible. The power stage has an overload and short circuit protection.

**4.1.2 Structure of a positioning control**

**Structure**

The figure below shows the structure of a typical positioning control



**Control**

The *Control* consists of the PLC with the user program for the processing and the motion module to control the drive. The motion module has an integrated power stage. This generated from the module signals the required drive currents. You can define a software limit switch in the motion module and react in the user program on the overrun.



**CAUTION!**

Please provide for track limits (general position limit) respectively to avoid damages besides software limit switch hardware limit switches and also consider this in your safety concept.

**Motor**

A DC motor is an engine for high-precision positioning. This consists of a fixed stator with permanent magnets and a rotating armature. The current supply to the armature winding happens by means of carbon brushes via the commutator as sliding contact. The individual armature windings are connected via the commutator, which serves as a pole changer. As soon as the armature winding is energized, a magnetic field builds up in the armature. This results, influenced by the permanent magnets, in a rotational movement of the armature. Due to the rotation the commutator reverses the polarity in the armature. In this way the rotational movement is continued steadily. Controlling a DC motor by means of pulse width modulation (PWM) is low-loss and has a high efficiency. With PWM, the start and stop time of a square-wave signal is varied at a fixed base frequency of 32kHz. This results in different average voltages. When selecting a motor, the following factors must be considered:

- Torque curve across the speed
- Motor current across the speed
- Winding resistance respectively motor inductance

**Encoder**

- The encoder respectively rotation encoder provides the controller with the position of the drive by means of digital signals. This can accordingly be evaluated by the PLC.
- The encoder respectively rotation encoder supply a certain number of pulses per revolution.
- The value generation is done by counting the pulses.

**Mechanical**

For the requirements of the load to be moved and the consideration of additional loads such as bearings and gears, you can determine the necessary motor data. Here important parameters are:


- Mass inertia
- Cycle times of positioning
- Start, holding and torque at the maximum required speed
- Acceleration and torque when passing through mechanical resonances e.g. when using mechanical memories as spring elements, vibration buffer or long drive belts.



*To avoid step losses, in accordance with the own inertia, the output torque of the engine should be greater than the determined mechanical torque.*


### 4.1.3 Encoder - signal evaluation

#### Signal evaluation



- Incremental encoder are sensors for detecting angular or positional changes.
- Depending on the sensor type and the desired resolution, the scanning happens by sliding contact, photo electrically or magnetically.
  - The scanning via *sliding contact* works in principle like a switch, which is mechanically operated.
  - With the *optical scanning* a disk, which has a fine raster, is optically scanned.
  - With the magnetic scanning a pole wheel or magnetic band is scanned which has been written with a raster by a magnetization, before.
- The incremental encoder has two sensors *Track A* and *Track B* for scanning.
- The sensors are arranged at an angle of 90 degrees from each other on the system to be scanned.

- In a rotational movement of the system, the sensors generate a specific number of pulses. These are a measure of the covered angle or way. With the electrical phase shift of the two signals the direction of rotation can be determined.
  - If the axis rotates to the right, then the signal of *Track A* is leading 90° towards the signal of *Track B*.
  - If the axis rotates to the left, then the signal of *Track A* is lagging 90° towards the signal of *Track B*.
- During the sensor evaluation from the difference between two counter values the velocity and direction can be determined.
- With *1-fold* evaluation one signal edge 0-1 of *Track A* corresponds to one counter pulse respectively one division of the system to be scanned corresponds to one counter pulse.
- With *4-fold* evaluation one signal edge of *Track A* and *Track B* corresponds to one counter pulse. The 4-fold evaluation is very often used.



#1 1-fold evaluation  
 #4 4-fold evaluation

## 4.2 Commissioning

### 4.2.1 Installation

1. ➔ Build your System SLIO and connect it. ↪ *Chap. 2 'Basics and mounting' page 8.*
2. ➔ Connect your drive. ↪ *Chap. 4.3 'Connecting a motor' page 61*

### 4.2.2 Inspections and tests before the test operation

#### Preparation

Please check the following items, and take appropriate measures in the event of an error, before you start the test operation.

- Are all wiring and connections correct?
- Are all nuts and bolts at the drive properly tightened?
- For a motor with oil seal: Is the seal not damaged and is the motor lubricated? Please always regard the start-up instructions of your motor!

### 4.2.3 Start-up of the System SLIO motion module

#### Preparation

Please check the following items, and take appropriate measures in the event of an error, before you start the test operation.

- Check the correct setting of the set points for the drive and the I/O signals from the superordinate control.
- Check wiring between the superordinate control and your drive as well as the polarity of the wires.
- Check all operational settings of your drive.

#### Setting the limits

Set the respective system limits, the system behavior and characteristics in the object dictionary via the *Acyclic channel* ↪ 98. These are e.g.:

- Behaviour at quick stop and on error
- Motor maximum current  
↪ *'0x8C00-04 - Motor max. current' page 153*
- Current limits  
↪ *'0x8600-04 - Current limit positive direction' page 145*  
↪ *'0x8600-05 - Current limit negative direction' page 145*
- Velocity limit values
- Position limitations
- Assignment of the digital inputs and outputs

## Steps of commissioning

**Always adapt parameters to the operating mode!**

Please ensure that the module always has the correct parameters according to the selected operating mode! Pay special attention to the use of the current values in the output area! ↪ Chap. 4.11 'In-/Output area' page 95

**Start parameter**

- ↪ 'Start - Start parameter homing' page 66
- ↪ 'Start - Start parameter PtP position profile' page 74
- ↪ 'Start - Start parameter velocity profile' page 85
- ↪ 'Start - Start parameter torque control' page 89

**1.** Perform for your System SLIO and your motion module a hardware configuration and create your application program. Transfer both into your CPU. A separate parametrization of the motion module is not required.

**2.**

**Power supply**

The module is to be power supplied with the both DC 24V voltages power section supply I/O area and electronic power supply. When commissioning these may simultaneously or electronic power supply must be switched on first. When commissioning these may simultaneously or power section supply I/O area must be switched on first. ↪ 'Standard wiring' page 27

Switch your CPU to RUN state.

**3.** Switch on the motor.

⇒ Your system is now ready for communication and you can establish parameter setting via the *Acyclic channel*.

**4.** Send the command "Shutdown".

↪ '0x8100-01 - Control word' page 121 Bit 3...0: x110

⇒ The motion module shows the state 'Ready to switch on'.

**5.** Send the command "Switch on".

↪ '0x8100-01 - Control word' page 121 Bit 3...0: 0111

⇒ The motion module shows the state 'Switched on'.

**6.** Send the command "Enable operation".

↪ '0x8100-01 - Control word' page 121 Bit 3...0: 1111


⇒ The motion module shows the state 'Operation enabled'. The drive is now ready for your move commands.



### 4.3 Connecting a motor



#### 4.3.1 Connection options

##### Connections



**CAUTION!**  
**Danger of injury from electrical shock and damage to the unit!**  
 Put the System SLIO in a safe, powered down state before starting installation, disassembly or wiring of the System SLIO modules!

- You can use wires with a cross section of 0.08mm<sup>2</sup> up to 1.5mm<sup>2</sup>. For the connection lines the following requirements apply:
- For the digital I/O connection with DIO operation single lines can be used. In encoder mode, shielded cables are to be used.
  - A motor must be connected via shielded lines.
  - Generally, power and signal lines must be laid separately.



Pos.	Function	Type	Description
1	PA1	O	DC Motor 1 - connection 1
2	PA2	O	DC Motor 1 - connection 2
3	I/O1	I/O	Digital input/output 1
4	I/O3	I/O	Digital input/output 3
5	PB1	O	DC Motor 2 - connection 1
6	PB2	O	DC Motor 2 - connection 2
7	I/O2	I/O	Digital input/output 2
8	I/O4	I/O	Digital input/output 4

I: Input, O: Output

**Power supply**  
 The module is to be power supplied with the both DC 24V voltages power section supply I/O area and electronic power supply. When commissioning these may simultaneously or electronic power supply must be switched on first. When commissioning these may simultaneously or power section supply I/O area must be switched on first. ↪ 'Standard wiring' page 27

## 4.4 Drive profile

### 4.4.1 Overview

#### Drive profile CiA 402

- The System SLIO motion module FM 054-1CB00 is based largely on the drive profile *CiA 402*.
- The drive profile *CiA 402* defines state machine, operating modes and objects (parameters) of components for the drive technology.
- Here significant objects for control and evaluation of the state machine are *Control word*, *Status word* and *Operation mode*.
- Further object serve for configuration and diagnostics of the motion module.
- All the object are summarized in ↗ *Chap. 5 'Object dictionary' page 108*.
- The most important objects can be found in ↗ *Chap. 4.11 'In-/Output area' page 95*.
- The access of the objects during runtime happens via ↗ *Chap. 4.12 'Acyclic channel' page 98*.

#### Term definitions

- State machine** - The motion module has a state machine implemented. The status of the state machine can be controlled by means of commands.
- State change** - The relevant command or any errors cause a state change.
- State** - The state is the current state of the state machine. Via the *Status word* ↗ *'0x8100-02 - Status word' page 122* you can access the state. Here the state is output via appropriate combinations of bits.
- Command** - For triggering of state transitions, certain combinations of bits must be set in the *Control word* ↗ *'0x8100-01 - Control word' page 121*. Such a combination is called *Command*.

#### Addressing

The System SLIO motion module provides its data, such as "Profiling target position" via an object dictionary. In this object dictionary the objects are organized and addressable a unique number consisting of *Index* and *Subindex*. The number is specified as follows:

0x	Index (hexadecimal)	-	Subindex (decimal)
Example: 0x8400-03			



To improve the structure and for expansion at System SLIO Motion Module another object numbering (index-assignment) is used besides the standard CiA 402.




#### Access to 2 drives

For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.

- Object dictionary drive 1: 0x8000 ... 0x8FFF
- Object dictionary drive 2: 0x9000 ... 0x9FFF

### 4.4.2 States

#### State machine according to CiA 402




- O Control power on  
Drive is not supplied with electricity
  - B Control and main power on  
Drive is not supplied with electricity
  - C Control and main power on  
Drive is supplied with electricity
  - xxx.. Status of the *Status word*
- Transition by:
- 0,1 Device start-up and self-test after PowerON
  - 13 Drive or communication error
  - 14 Internal fault reaction
  - 16 Disabling command output disable (BASP)  
↳ '0x8100-01 - Control word' page 121:
  - 2,6 Bit 3...0: x110: Command "Shutdown"
  - 3 Bit 3...0: 0111: Command "Switch on"
  - 4 Bit 3...0: 1111: Command "Enable operation".  
According to CiA 402 the automatic transition from *Ready to switch on* to *Operation enabled* is possible.
  - 5 Bit 3...0: 0111: Command "Disable operation"

- 11 Bit 3...0: x01x: Command "Quick stop"
- 7,8,9,12 Bit 3...0: xx0x: Command "Disable voltage"
- 15 Bit 7: Edge 0-1: Command "Fault reset"

**Accessing the state machine**

At CiA 402 the total control is realized via the following two objects. Both objects are mapped in the cyclic data exchange:



**4.4.3 Operating modes**

4.4.3.1 Overview

**Operating modes**

The communication takes place via the I/O area. The main data of the object dictionary are mapped into the I/O area.

↳ Chap. 4.11 'In-/Output area' page 95

The objects, which are not mapped, can be accessed by the *Acyclic channel*.


↳ Chap. 4.12 'Acyclic channel' page 98

The following modes according to the device profile CiA 402 are available:

- ↳ Chap. 4.5 'Homing' page 65
- ↳ Chap. 4.6 'PtP positioning profile' page 72
- ↳ Chap. 4.7 'Velocity profile' page 84
- ↳ Chap. 4.8 'Torque control' page 88

**Controller structure and controller parameters**

Basis of the individual modes is the cascaded controller structure of the System SLIO motion module. This will give you a high dynamic and position precision. The set point for the higher-level position controller is generated by the profile generators of the individual modes. Positioning and Velocity control loop can be closed, this means if configured the encoder signal is used for control. This structure consists of the following components:



- Start: Start parameters
- Limit: Limitations
- Vel control: Velocity control - 8kHz clock
- Position control: Position controller - 8kHz clock
- PI: PI current controller - 32kHz clock
- int. PS: Internal power stage (power stage)
- Encoder: Encoder current value

**Application data**

In addition to the control parameters you have to specify the data from your application, consisting of the nominal drive data and scaling.

<a href="#">🔗 '0x8180-02 - Gear factor' page 128</a>	→	Application data
<a href="#">🔗 '0x8C00-04 - Motor max. current' page 153</a>		
<a href="#">🔗 '0x8C00-06 - Motor nominal velocity' page 153</a>		

## 4.5 Homing

**Overview**

Here you will find information on how the System SLIO motion module searches the *reference position*. The reference position is also called "basic position", "start position" or "home position". *Homing* is an initialisation drive of a drive, where the correct position is determined by means of an reference signal. This process is called "referencing", "home drive" or "homing".

When referencing you can determine velocity, acceleration, deceleration and type of homing. The FM 054-1CB00 supports the following homing types:

- [🔗 Chap. 4.5.1 'Homing by means of a homing switch' page 67](#)
- [🔗 Chap. 4.5.2 'Homing to current position' page 69](#)
- [🔗 Chap. 4.5.3 'Homing by means of current limitation' page 70](#)

Homing

**Start - Start parameter homing**



Please note:



- ↪ Chap. 4.2 'Commissioning' page 59
- ↪ 'Application data' page 65

<p>↪ '0x8280-01 - Operating mode requested' page 130</p> <p>6: Homing mode</p> <p>( ↪ '0x8280-02 - Operating mode actual' page 131 )</p>	→	Homing	→	<p>↪ '0x8100-02 - Status word' page 122</p>		
<p>↪ '0x8300-02 - Homing method' page 131</p>				↪	↪	↪ '0x8280-02 - Operating mode actual' page 131
<p>↪ '0x8300-03 - Homing digital input I/O1...I/O4' page 132</p>						
<p>↪ '0x8300-04 - Homing digital input active polarity I/O1...I/O4' page 132</p>						
<p>↪ '0x8300-05 - Homing target position' page 133</p>						
<p>↪ '0x8300-06 - Homing velocity V1' page 133</p>						
<p>↪ '0x8300-07 - Homing velocity V2' page 133</p>						
<p>↪ '0x8300-08 - Homing acceleration' page 134</p>						
<p>↪ '0x8300-09 - Homing deceleration' page 134</p>						
<p>↪ '0x8300-10 - Homing offset value' page 134</p>						

### 4.5.1 Homing by means of a homing switch

#### Homing by means of a homing switch

- Homing can only be accessed from the *PtP positioning profile* mode.
- The *target position* is the reference position, which is maximally moved to. This is to be specified with sign.
- The homing happens according to the following steps:
  - It is traversed with the high *velocity V1* toward the target position *T* until the homing switch *R* is overrun.
  - Then it is decelerated and traversed in the opposite direction with *velocity V1*.
  - If the homing value *R* is overrun again, it is again decelerated and it is again accelerated in the positive direction with slower *velocity V2*.
  - With the next overrun of the homing switch the reference position *R* is set and moved to with *velocity V2*.
- Use To connect the home switch one of the digital inputs of the motion module and specify the polarity of the switch with the parametrization.



- $V_1$  High velocity
- $V_2$  Low velocity
- R Homing switch respectively homing value
- T Target position
- L General position limit

**Proceeding**

1. ➤ For commissioning ↪ *Chap. 4.2 'Commissioning' page 59*  
Homing objects ↪ *Chap. 5.2.11 'Homing - 0x8300' page 131*
2. ➤ ■ Switch the state machine to state 'Switch on disabled' ↪ *Chap. 4.4.2 'States' page 63*
  - Send the command "Disable voltage"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: xx0x:
  - ⇒ The motion module shows the state 'Switch on disabled'.
3. ➤ Set the following parameters:
  - ↪ '0x8300-02 - Homing method' page 131
    - Enter the value 17.
  - ↪ '0x8300-03 - Homing digital input I/O1...I/O4' page 132
    - Select the input to which the homing switch is connected.
  - ↪ '0x8300-04 - Homing digital input active polarity I/O1...I/O4' page 132
    - Define the polarity of the switch
  - ↪ '0x8300-05 - Homing target position' page 133
    - Define by specifying a target position the maximum axis movement path, that during movement the homing switch is passed over.
  - ↪ '0x8300-06 - Homing velocity V1' page 133
    - Specify the high velocity for the movement to the homing switch.
  - ↪ '0x8300-07 - Homing velocity V2' page 133
    - Specify the low velocity for the movement to the homing switch.
  - ↪ '0x8300-08 - Homing acceleration' page 134
    - Specify the acceleration for homing.
  - ↪ '0x8300-09 - Homing deceleration' page 134
    - Specify the deceleration for homing.
  - ↪ '0x8300-10 - Homing offset value' page 134
    - If necessary specify an offset for the homing position.
4. ➤ ■ ↪ '0x8400-03 - Positioning profile target velocity' page 135
  - Enter the value 0.
5. ➤ ■ Switch your motion module to the *Positioning* mode. ↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 1.
6. ➤ Send the command "Shutdown"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: x110:  
⇒ The motion module shows the state 'Ready to switch on'.
7. ➤ Send the command "Switch on".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 0111  
⇒ The motion module shows the state 'Switched on'.
8. ➤ Send the command "Enable operation".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 1111  
⇒ The motion module shows the state 'Operation enabled'. The drive is now ready for your move commands.
9. ➤ ■ Switch your motion module to the *Homing* mode. ↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 6.
  - ⇒ The drive starts homing. Upon completion of the homing, the position of the reference switch is used as the reference point.



## 4.5.2 Homing to current position

### Proceeding

1. ➤ For commissioning ↪ *Chap. 4.2 'Commissioning' page 59*  
Homing objects ↪ *Chap. 5.2.11 'Homing - 0x8300' page 131*
2. ➤ ■ Switch the state machine to state 'Switch on disabled' ↪ *Chap. 4.4.2 'States' page 63*
  - Send the command "Disable voltage"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: xx0x:

⇒ The motion module shows the state 'Switch on disabled'.
3. ➤ Set the following parameters:
  - ↪ '0x8300-02 - Homing method' page 131
    - Enter the value 37.
  - ↪ '0x8300-10 - Homing offset value' page 134
    - If necessary specify an offset for the homing position.
4. ➤ ■ ↪ '0x8400-03 - Positioning profile target velocity' page 135
  - Enter the value 0.
5. ➤ ■ Switch your motion module to the *Positioning* mode. ↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 1.
6. ➤ Send the command "Shutdown"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: x110:  
⇒ The motion module shows the state 'Ready to switch on'.
7. ➤ Send the command "Switch on".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 0111  
⇒ The motion module shows the state 'Switched on'.
8. ➤ Send the command "Enable operation".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 1111  
⇒ The motion module shows the state 'Operation enabled'. The drive is now ready for your move commands.
9. ➤ ■ Switch your motion module to the *Homing* mode.  
↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 6.



⇒ The current position is directly taken as a reference point in consideration to the offset.  
↪ '0x8300-10 - Homing offset value' page 134

The motion module then automatically switches back to the *Positioning* mode.

### 4.5.3 Homing by means of current limitation

#### Homing by means of current limitation

- Homing can only be accessed from the *PtP positioning profile* mode.
- If homing is completed, it is returned to the *PtP positioning profile* mode, again.
- The *target position* is the reference position, which is maximally moved to. This is to be specified with sign.
- The homing happens according to the following steps:
  - It is traversed with the high *velocity*  $V_1$  toward the target position  $T$  until the drive is stopped by a soft stop.
  - If a predefined limit current is exceeded, the current position is set as homing position  $R$ .
  - To move the drive free, you can also specify an offset.



- $V_1$  High velocity
- $V_2$  Low velocity
- R Homing switch respectively homing value
- T Target position
- L General position limit

## Proceeding

1. ➤ For commissioning ↪ *Chap. 4.2 'Commissioning' page 59*  
Homing objects ↪ *Chap. 5.2.11 'Homing - 0x8300' page 131*
2. ➤ ■ Switch the state machine to state 'Switch on disabled' ↪ *Chap. 4.4.2 'States' page 63*
  - Send the command "Disable voltage"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: xx0x:
  - ⇒ The motion module shows the state 'Switch on disabled'.
3. ➤ ■ ↪ '0x8400-03 - Positioning profile target velocity' page 135
  - Enter the value 0.
4. ➤ ■ Switch your motion module to the *Positioning* mode. ↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 1.
5. ➤ Set the following parameters:
  - ↪ '0x8300-02 - Homing method' page 131
    - Enter the value -1 for homing by means of current limitation.
  - ↪ '0x8600-04 - Current limit positive direction' page 145 respectively  
↪ '0x8600-05 - Current limit negative direction' page 145
    - Specify the limit currents.
  - ↪ '0x8300-05 - Homing target position' page 133
    - Define by specifying a target position the maximum axis movement path, that during movement the soft stop is hit.
  - ↪ '0x8300-06 - Homing velocity V1' page 133
    - Specify the high velocity for the movement to the soft stop.
  - ↪ '0x8300-07 - Homing velocity V2' page 133
    - Specify the low velocity for the free movement from the soft stop.
  - ↪ '0x8300-08 - Homing acceleration' page 134
    - Specify the acceleration for homing.
  - ↪ '0x8300-09 - Homing deceleration' page 134
    - Specify the deceleration for homing.
  - ↪ '0x8300-10 - Homing offset value' page 134
    - If necessary specify an offset for the homing position.
6. ➤ Send the command "Shutdown"  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: x110:  
⇒ The motion module shows the state 'Ready to switch on'.
7. ➤ Send the command "Switch on".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 0111  
⇒ The motion module shows the state 'Switched on'.
8. ➤ Send the command "Enable operation".  
↪ '0x8100-01 - Control word' page 121 Bit 3...0: 1111  
⇒ The motion module shows the state 'Operation enabled'. The drive is now ready for your move commands.
9. ➤ ■ Switch your motion module to the *Homing* mode. ↪ '0x8280-01 - Operating mode requested' page 130
  - Enter the value 6.
  - ⇒ The drive starts homing. Upon completion of the homing, the position of the soft stop is used as the reference point. The motion module then automatically switches back to the *Positioning* mode.

## 4.6 PtP positioning profile

### Overview



#### **Always adapt parameters to the operating mode!**

Please ensure that the module always has the correct parameters according to the selected operating mode! Pay special attention to the use of the current values in the output area! ↪ Chap. 4.11 'In-/Output area' page 95

#### *Start parameter*

- ↪ 'Start - Start parameter homing' page 66
- ↪ 'Start - Start parameter PtP position profile' page 74
- ↪ 'Start - Start parameter velocity profile' page 85
- ↪ 'Start - Start parameter torque control' page 89


With the PTP-position profile, you can move to target positions by specifying profile velocity, profile acceleration and profile deceleration. Here, the limits for velocity and maximum traversing position are always be considered. Due to changes of values are immediately used and activated, "on the fly" changes of the move process are possible.

- Changes in acceleration respectively deceleration are directly used with the profile generation.
- Deceleration and reversing is automatically executed when a new target position requires a change of direction. A separated activation by starting the job in the *Control word* is not necessary.
- If a specified target position is reached or a limit is activated during the traversing, this is indicated in ↪ '0x8100-02 - Status word' page 122.
- Current values of position, velocity, acceleration and deceleration are calculated by the System SLIO motion module itself.

There are the following possibilities to evaluate the encoder signal ↪ '0x8F00-01 - Encoder Feedback configuration' page 155:

- controlled mode
  - The System SLIO motion module works in a controlled mode.
  - Positioning and velocity loops are open
  - There is no evaluation of the encoder signal
  - Current values of position, velocity, acceleration and deceleration are calculated by the System SLIO motion module itself.
- closed-loop mode
  - The System SLIO motion module works in a closed-loop mode
  - Positioning and velocity loops are closed
  - The encoder signal is evaluated and from this the current values of position, velocity, acceleration and deceleration are determined.

Structure




PtP positioning profile

**Start - Start parameter PtP position profile**



Please note:


- ↪ Chap. 4.2 'Commissioning' page 59
- ↪ 'Application data' page 65




**Vel - velocity profile**




**Limit - limitation velocity**




**Velocity control - Velocity control**




**PtP - Positioning profile generator**




**Limit Position - Limitation position**



**Position control - Position controller**




**Limit Current - Limitation current**







**PI - PI current controller**



**Limit Voltage - Limitation voltage**




**int. PS - Internal power stage, motor, encoder**



### 4.6.1 Examples

#### Symmetrical acceleration and deceleration with reaching the target velocity


- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is reached.
- Specifying a new target position as starting position.



V Velocity  
 A Acceleration  
 P Position  
 t Time

### Symmetrical acceleration and deceleration without reaching the target velocity


- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is not reached, since before deceleration is initiated to reach the target position.
- Specifying a new target position as starting position.



V Velocity  
 A Acceleration  
 P Position  
 t Time

**Asymmetrical acceleration and deceleration with reaching the target velocity**


- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is reached.
- Specifying a new target position as starting position.



V Velocity  
 A Acceleration  
 P Position  
 t Time

### Asymmetrical acceleration and deceleration with reducing the acceleration during the move


- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is reached.
- Specifying a new target position as starting position.



V Velocity  
 A Acceleration  
 P Position  
 t Time

**Symmetrical acceleration and deceleration with reaching the target velocity**


- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is reached.
- Specifying a new target position as starting position during deceleration.



V Velocity  
 A Acceleration  
 P Position  
 t Time

### Symmetrical acceleration and deceleration with specifying a target position, twice

- Setting
  - Target position
  - Profile velocity
  - Profile acceleration
  - Profile deceleration
- Target velocity is reached.
- Specifying a new target position, after the previous target position was reached.



V Velocity  
 A Acceleration  
 P Position  
 t Time

## 4.7 Velocity profile

### Structure




**Always adapt parameters to the operating mode!**

Please ensure that the module always has the correct parameters according to the selected operating mode! Pay special attention to the use of the current values in the output area! ↪ Chap. 4.11 'In-/Output area' page 95

**Start parameter**

- ↪ 'Start - Start parameter homing' page 66
- ↪ 'Start - Start parameter PtP position profile' page 74
- ↪ 'Start - Start parameter velocity profile' page 85
- ↪ 'Start - Start parameter torque control' page 89

In the operation mode *Velocity profile* the velocity is output according to profile acceleration and profile deceleration until the target velocity is reached. This operation mode bases on the *PtP positioning profile*, except that position settings such as target and limit values have no effect. With this object ↪ '0x8500-01 - Velocity control configuration' page 140, you can specify the frequency pulse patterns.



- Start: Start parameters
- Limit Velocity: Limitation velocity
- Limit Current: Limitation current
- Limit Voltage: Limitation voltage
- Vel: Velocity profile
- Vel control: Velocity control

- PtP: PtP positioning profile
- Position control: Position controller
- PI: PI current controller
- int. PS: Internal power stage
- M: Motor
- Encoder: Encoder current value




**Start - Start parameter velocity profile**




Please note:


- [Chap. 4.2 'Commissioning' page 59](#)
- ['Application data' page 65](#)




**Vel - velocity profile**




**Limit - limitation velocity**




**Velocity control - Velocity control**




**PtP - Positioning profile generator**




**Position control - Position controller**




**Limit Current - Limitation current**




**PI - PI current controller**



**Limit Voltage - Limitation voltage**



**int. PS - Internal power stage, motor, encoder**



**4.8 Torque control**

**Structure**




**Always adapt parameters to the operating mode!**

Please ensure that the module always has the correct parameters according to the selected operating mode! Pay special attention to the use of the current values in the output area! ↳ Chap. 4.11 'In-/Output area' page 95

**Start parameter**

- ↳ 'Start - Start parameter homing' page 66
- ↳ 'Start - Start parameter PtP position profile' page 74
- ↳ 'Start - Start parameter velocity profile' page 85
- ↳ 'Start - Start parameter torque control' page 89

In the operating mode *Torque control* a current set value is outputted to the drive. If the actual current exceeds the permissible motor current, there is an error reaction of the motion module, which can be configured. Also you can set with ↳ '0x8500-01 - Velocity control configuration' page 140 how the engine behaves when reaching the permissible motor current.




- Start: Start parameters
- Limit Current: Limitation current
- Limit Voltage: Limitation voltage
- Limit Velocity: Limitation velocity
- PI: PI current controller
- int. PS: Internal power stage
- M: Motor
- Encoder: Encoder current value

**Start - Start parameter torque control**




Please note:


- [Chap. 4.2 'Commissioning' page 59](#)
- ['Application data' page 65](#)




**Limit Current - Limitation current**



**PI - PI current controller**



**Limit Voltage - Limitation voltage**



**int. PS - Internal power stage, motor, encoder**



**4.9 Deployment I/O1...I/O4**

**Overview**


The module has 4 digital connectors I/O1...I/O4. The ports can be used with the following configurable modes:

- Used as digital input
- Used as digital output
- Pairs use as encoder input for 24V HTL signal

**Default settings**

The 4 digital ports of the motion module have the following default settings:

**Default setting**




Pos.	Function	Type	Description
3	I/O1	I	Digital input
4	I/O3	I	Digital input
7	I/O2	I	Digital input
8	I/O4	I	Digital input

I: Input, O: Output




Via [Chap. 5.2.5 'Digital inputs I/O1...I/O4 - 0x7100'](#) page 115 respectively [Chap. 5.2.6 'Digital output I/O1...I/O4 - 0x7200'](#) page 117 the 4 digital pins of the motion modules can be configured.

**Connections**




Digital input: DC 24V  
IEC 61131-2 type 3  
High-side (sink)

Deployment I/O1...I/O4 > Usage as input for encoder



Digital output: DC 24V  
500 mA  
High-side (source)



Encoder mode: 24V HTL signal  
Phase A and B  
100 kHz  
4-fold evaluation  
↳ Chap. 4.9.2.2 'Encoder - deployment' page 93

### 4.9.1 Objects

#### Structure


#### DIO Control



### 4.9.2 Usage as input for encoder

#### 4.9.2.1 Encoder - signal evaluation


#### Signal evaluation



- Incremental encoders are sensors for detecting angular or positional changes.
- Depending on the sensor type and the desired resolution, the scanning happens by sliding contact, photo electrically or magnetically.
  - The scanning via *sliding contact* works in principle like a switch, which is mechanically operated.
  - With the *optical scanning* a disk, which has a fine raster, is optically scanned.
  - With the magnetic scanning a pole wheel or magnetic band is scanned which has been written with a raster by a magnetization, before.
- The incremental encoder has two sensors *Track A* and *Track B* for scanning.
- The sensors are arranged at an angle of 90 degrees from each other on the system to be scanned.
- In a rotational movement of the system, the sensors generate a specific number of pulses. These are a measure of the covered angle or way. With the electrical phase shift of the two signals the direction of rotation can be determined.
  - If the axis rotates to the right, then the signal of *Track A* is leading 90° towards the signal of *Track B*.
  - If the axis rotates to the left, then the signal of *Track A* is lagging 90° towards the signal of *Track B*.
- During the sensor evaluation from the difference between two counter values the velocity and direction can be determined.



- With 1-fold evaluation one signal edge 0-1 of *Track A* corresponds to one counter pulse respectively one division of the system to be scanned corresponds to one counter pulse.
- With 4-fold evaluation one signal edge of *Track A* and *Track B* corresponds to one counter pulse. The 4-fold evaluation is very often used.




#1 1-fold evaluation  
 #4 4-fold evaluation

### 4.9.2.2 Encoder - deployment

#### Connections

There is the possibility to connect an encoder via I/O1 and I/O3 respectively via I/O2 and I/O4. With the value 1 of object [‘0x8F00-01 - Encoder Feedback configuration’ page 155](#) the encoder function for I/O1 and I/O3 of drive 1 is enabled. The System SLIO motion module works in a closed-loop mode Positioning and velocity loops are closed Current values of position, velocity, acceleration and deceleration are calculated by the System SLIO motion module itself. Via [‘0x8F00-02 - Encoder actual value’ page 155](#) the encoder value can be read and further processed in you user program. If there is one encoder connected, the unused digital in-/outputs are further free for usage.


#### Objects



\*) For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.


- Object dictionary drive 1 (I/O1 and I/O3): 0x8000 ... 0x8FFF
- Object dictionary drive 2 (I/O2 and I/O4): 0x9000 ... 0x9FFF

#### Connections



Encoder mode: 24V HTL signal  
 Phase A and B  
 100 kHz  
 4-fold evaluation

Deployment I/O1...I/O4 > Usage as input for encoder



Pos.	Function	Type	Description
3	I/O1	I	Encoder function drive 1
4	I/O3	I	Encoder function drive 1
7	I/O2	I	Encoder function drive 2
8	I/O4	I	Encoder function drive 2
I: Input			



Via ↗ Chap. 5.2.5 'Digital inputs I/O1...I/O4 - 0x7100' page 115 respectively ↗ Chap. 5.2.6 'Digital output I/O1...I/O4 - 0x7200' page 117 the 4 digital pins of the motion modules can be configured.

## 4.10 Brake control

### Overview

You can control a brake via a digital input/output channel. For brake control you have the following possibilities:

- Braking via external brake
- Quick stop via ramping

### Braking via external brake

You have the possibility to control a brake via a digital input/output channel. By integration into your user program, you can control it if necessary.


### Quick stop

Quick stop is a ramp function, with which the connected motor can be decelerated and brought to stop. During normal operation it is not necessary to activate this brake functions manually, since normal braking operations are performed by the profile generator. Quick stop is used when the operating conditions require a rapid stopping.

For quick stop there are the following possibilities:

- Direct stop with short-circuit braking and subsequent state change to 'Switch on disabled'.
- Brake with quick stop deceleration and state change to 'Switch on disabled'.

### Quick stop - objects



## 4.11 In-/Output area

### Overview

The motion module uses 60byte input and 60byte output data.

Head module	Backplane bus	Motion module	
CPU respectively bus coupler	→	Process data	Acyclic channel
	←	60byte	



The data exchange with the motion module must be consistent across the 60 bytes! It is recommended to control it via the process image.

### Input area

Offset	Size	Area	Description
0	2	Drive 1	🔗 '0x8100-02 - Status word' page 122
2	2	Drive 1	🔗 '0x8280-02 - Operating mode actual' page 131
4	4	Drive 1	🔗 '0x8480-02 - Position actual value' page 136

## In-/Output area

Offset	Size	Area	Description
8	4	Drive 1	☞ '0x8500-02 - Velocity control actual value' page 140
12	4	Drive 1	☞ '0x8580-02 - Acceleration/Deceleration actual value' page 143
16	4	Drive 1	☞ '0x8480-10 - Lag error' page 138
20	2	Drive 1	☞ '0x8600-02 - Current actual value' page 144
22	2	-	reserved
24	2	Drive 2	* ☞ '0x8100-02 - Status word' page 122
26	2	Drive 2	* ☞ '0x8280-02 - Operating mode actual' page 131
28	4	Drive 2	* ☞ '0x8480-02 - Position actual value' page 136
32	4	Drive 2	* ☞ '0x8500-02 - Velocity control actual value' page 140
36	4	Drive 2	* ☞ '0x8580-02 - Acceleration/Deceleration actual value' page 143
40	4	Drive 2	* ☞ '0x8480-10 - Lag error' page 138
44	2	Drive 2	* ☞ '0x8600-02 - Current actual value' page 144
46	2	-	reserved
48	1	DIOs	☞ '0x7100-05 - Digital input states I/O1...I/O4' page 117
49	1	DIOs	☞ '0x7200-05 - Digital output states I/O1...I/O4 actual states' page 119
50	1	Acyclic	Acyclic communication channel: Status
51	1	Acyclic	Acyclic communication channel: Subindex in the object dictionary
52	2	Acyclic	Acyclic communication channel: Index in the object dictionary
54	4	Acyclic	Acyclic communication channel: Data
58	1	-	reserved
59	1	-	reserved

\*) For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.

- Object dictionary drive 1: 0x8000 ... 0x8FFF
- Object dictionary drive 2: 0x9000 ... 0x9FFF



Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.

## Output area

Offset	Size	Area	Description
0	2	Drive 1	↳ '0x8100-01 - Control word' page 121
2	2	Drive 1	↳ '0x8280-01 - Operating mode requested' page 130
4	4	Drive 1	↳ '0x8400-02 - Positioning profile target position' page 135
8	4	Drive 1	↳ '0x8400-03 - Positioning profile target velocity' page 135
12	4	Drive 1	↳ '0x8400-04 - Positioning profile target acceleration' page 136
16	4	Drive 1	↳ '0x8400-05 - Positioning profile target deceleration' page 136
20	2	Drive 1	The assignment depends on the selected operating modes <ul style="list-style-type: none"> <li>■ Torque control enabled <ul style="list-style-type: none"> <li>– ↳ '0x8600-03 - Current target value' page 144</li> </ul> </li> <li>■ Torque control disabled <ul style="list-style-type: none"> <li>– ↳ '0x8600-04 - Current limit positive direction' page 145</li> <li>respectively</li> <li>↳ '0x8600-05 - Current limit negative direction' page 145</li> </ul> </li> </ul>
22	2	-	reserved
24	2	Drive 2	↳ '0x8100-01 - Control word' page 121*
26	2	Drive 2	↳ '0x8280-01 - Operating mode requested' page 130*
28	4	Drive 2	↳ '0x8400-02 - Positioning profile target position' page 135*
32	4	Drive 2	↳ '0x8400-03 - Positioning profile target velocity' page 135*
36	4	Drive 2	↳ '0x8400-04 - Positioning profile target acceleration' page 136*
40	4	Drive 2	↳ '0x8400-05 - Positioning profile target deceleration' page 136*
44	2	Drive 2	The assignment depends on the selected operating modes <ul style="list-style-type: none"> <li>■ Torque control enabled <ul style="list-style-type: none"> <li>– ↳ '0x8600-03 - Current target value' page 144*</li> </ul> </li> <li>■ Torque control disabled <ul style="list-style-type: none"> <li>– ↳ '0x8600-04 - Current limit positive direction' page 145*</li> <li>respectively</li> <li>↳ '0x8600-05 - Current limit negative direction' page 145*</li> </ul> </li> </ul>
46	2	-	reserved
48	1	-	reserved
49	1	Drive	↳ '0x7200-06 - Digital output states I/O1...I/O4 requested states' page 120
50	1	Acyclic	Acyclic communication channel: Command
51	1	Acyclic	Acyclic communication channel: Subindex in the object dictionary
52	2	Acyclic	Acyclic communication channel: Index in the object dictionary
54	4	Acyclic	Acyclic communication channel: Data
58	1	-	reserved

Acyclic channel

Offset	Size	Area	Description
59	1	-	reserved

\*) For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.

- Object dictionary drive 1: 0x8000 ... 0x8FFF
- Object dictionary drive 2: 0x9000 ... 0x9FFF

## 4.12 Acyclic channel

### Overview



Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.

Via the *Acyclic channel* you can perform acyclic read and write commands. For this in the input/output area of the motion module a data area for the acyclic communication has been implemented. This area includes 8 bytes output and 8 bytes input data. These have the following assignment:

Request		Response
Output data		Input data
<ul style="list-style-type: none"> <li>■ Byte 0: CMD - Command</li> <li>■ Byte 1: SUBIDX - Subindex</li> <li>■ Byte 2: IDX0 - Index (low byte)</li> <li>■ Byte 3: IDX1 - Index (high byte)</li> <li>■ Byte 4: DATA0 - Data (low byte)</li> <li>■ Byte 5: DATA1 - Data</li> <li>■ Byte 6: DATA2 - Data</li> <li>■ Byte 7: DATA3 - Data (high byte)</li> </ul>	→ ←	<ul style="list-style-type: none"> <li>■ Byte 0: STATUS - Status</li> <li>■ Byte 1: SUBIDX - Subindex</li> <li>■ Byte 2: IDX0 - Index (low byte)</li> <li>■ Byte 3: IDX1 - Index (high byte)</li> <li>■ Byte 4: DATA0 - Data (low byte)</li> <li>■ Byte 5: DATA1 - Data</li> <li>■ Byte 6: DATA2 - Data</li> <li>■ Byte 7: DATA3 - Data (high byte)</li> </ul>
IDLE → Request → Response → IDLE		

### CMD - Command

Code	Name	Description
0x11	READ_ONCE	Reading a data object With this command you can request the data once after the command has been recognized.
0x21	WRITE_ONCE	Writing a data object With this command data are written only once after the command has been recognized.

**SUBIDX - Subindex**                      Subindex in the object dictionary

**IDX0/IDX1 - Index**                      Index in the object dictionary

**DATA0 ... DATA3 - Data**      Data which are to be transmitted.

### STATUS - Status

Code	Name	Description
0x00	IDLE	Idle - waiting for commands
0x14	READ_ONCE	Command READ_ONCE has been recognized, data are valid.
0x24	WRITE_ONCE	Command WRITE_ONCE has been recognized, data were accepted.
0x81:	READ_NOT_EXIST	Error - read access - data do not exist Command rejected!
0x91	WRITE_NOT_EXIST	Error - write access - data do not exist Command rejected!
0x92	WRITE_RNG_ERR	Error - write access - data out of range Command rejected!
0x93	WRITE_RDO_ERR	Error - write access - data can only be read Command rejected!
0x94	WRITE_WPR_ERR	Error - write access - data are write protected Command rejected!
0x99	ACYC_COM_ERR	Error during acyclic communication Command rejected!

For the VIPA *SPEED7 Studio* and the Siemens SIMATIC Manager there is the block FB 320 ACYC\_RW for simplified access available.



*More information about the usage of this block may be found in the manual "SPEED7 Operation List" from Yaskawa.*

## 4.13 Parameter data

Here via the parameters you may define among others:

- Interrupt behavior
- Universal parameter

### 4.13.1 Parameter

DS - Record set for access via CPU, PROFIBUS and PROFINET

IX - Index for access via CANopen

SX - Subindex for access via EtherCAT with Index 3100h + EtherCAT-Slot

More can be found in the according manual of your bus coupler.

Parameter data &gt; Parameter

Name	Bytes	Function	Default	DS	IX	SX
DIAG_EN	1	Diagnostic interrupt *	00h	00h	3100h	01h
IDX_1	2	Universal parameter 1: Index	00h	80h	3101h...3102h	02h
SUBIDX_1	2	Universal parameter 1: Sub-index	00h	80h	3103h...3104h	03h
DATA_1	4	Universal parameter 1: Value	00h	80h	3105h...3108h	04h
IDX_2	2	Universal parameter 2: Index	00h	81h	3109h...310Ah	05h
SUBIDX_2	2	Universal parameter 2: Sub-index	00h	81h	310Bh...310Ch	06h
DATA_2	4	Universal parameter 2: Value	00h	81h	310Dh...3110h	07h
IDX_3	2	Universal parameter 3: Index	00h	82h	3111h...3112h	08h
SUBIDX_3	2	Universal parameter 3: Sub-index	00h	82h	3113h...3114h	09h
DATA_3	4	Universal parameter 3: Value	00h	82h	3115h...3118h	0Ah
IDX_4	2	Universal parameter 4: Index	00h	83h	3119h...311Ah	0Bh
SUBIDX_4	2	Universal parameter 4: Sub-index	00h	83h	311Bh...311Ch	0Ch
DATA_4	4	Universal parameter 4: Value	00h	83h	311Dh...3120h	0Dh
IDX_5	2	Universal parameter 5: Index	00h	84h	3121h...3122h	0Eh
SUBIDX_5	2	Universal parameter 5: Sub-index	00h	84h	3123h...3124h	0Fh
DATA_5	4	Universal parameter 5: Value	00h	84h	3125h...3128h	10h
IDX_6	2	Universal parameter 6: Index	00h	85h	3129h...312Ah	11h
SUBIDX_6	2	Universal parameter 6: Sub-index	00h	85h	312Bh...312Ch	12h
DATA_6	4	Universal parameter 6: Value	00h	85h	312Dh...3130h	13h
IDX_7	2	Universal parameter 7: Index	00h	86h	3131h...3132h	14h
SUBIDX_7	2	Universal parameter 7: Sub-index	00h	86h	3133h...3134h	15h
DATA_7	4	Universal parameter 7: Value	00h	86h	3135h...3138h	16h

\*) This record set may only be transferred at STOP state.



For the VIPA *SPEED7 Studio* and the Siemens SIMATIC Manager there is the block FB 321 - ACYC\_DS for simplified access available.



More information about the usage of this block may be found in the manual "SPEED7 Operation List" from Yaskawa.

## 4.14 Scaling and units

### Scaling and units

- As a "normalization" for position, velocity and acceleration, you can specify a *Gear factor* ↗ '0x8180-02 - Gear factor' page 128 in the object dictionary. This gear factor represents *units* in thousands with the rotary axis makes exactly one revolution.

### Direction of rotation

Positive direction of rotation is turning to the right (clockwise) with view towards the motor flange.

### Current unit

- All currents are normalized to the unit [mA].
- [User] is a user-defined unit, which depends on the *Gear factor*. ↗ '0x8180-02 - Gear factor' page 128

## 4.15 Monitoring and error reaction

### 4.15.1 Overview

#### General

The System SLIO motion module has monitor functions. The monitoring works in 3 steps:

- 1. Limitation
  - Status: ↗ '0x8100-04 - Limit active bits' page 125
  - Limitations within the normal operating range, adapted to the respective application.
- 2. Warning
  - Status: ↗ '0x8100-05 - Warnings active bits' page 126
  - The permissible operating range is almost exhausted and the system is about to initiate a fault response.
- 3. Error
  - Status: ↗ '0x8100-06 - Error active bits' page 127
  - The permissible operating range is exceeded and a configurable fault response is automatically triggered.
  - Error messages are also shown via ↗ '0x8100-02 - Status word' page 122.



#### CAUTION!

Please consider that incorrectly set monitoring functions can cause damages to persons and materials!

### Voltage monitoring

The voltage of DC 24V module power supply and the internal control voltage of the output stages are monitored. If the voltage over or under runs the limit values, a warning or error is reported by ↗ '0x8100-02 - Status word' page 122. On an error, there is an error reaction of the motion module, which can be configured.

- Temperature monitoring** The motion module has an internal temperature monitoring of the  $\mu$ -controller and the power stage. Via the object dictionary limit temperatures can be defined. If the temperature over or under runs the limit values, there is an error reaction of the motion module, which can be configured. ↪ *'0x8780-02 - Temperature  $\mu$ -Controller actual value'* page 151
- Current monitoring** The by the power stages driven current ↪ *'0x8600-03 - Current target value'* page 144 in the windings of the motor is monitored. The target current is limited to a configurable value ↪ *'0x8600-04 - Current limit positive direction'* page 145 respectively ↪ *'0x8600-05 - Current limit negative direction'* page 145 and with active limitation reported via ↪ *'0x8100-02 - Status word'* page 122. If the actual current exceeds the permissible motor current ↪ *'0x8C00-04 - Motor max. current'* page 153, there is an error reaction of the motion module, which can be configured.
- Position monitoring** The motion module monitors the traversing of a positioning. When specifying a target position, with exceeding a configurable limit in positive or negative direction of movement, the target position changed to a limit value. You will get a feedback on an active limitation via ↪ *'0x8100-02 - Status word'* page 122. Exceeds the actual position one of the configurable values in positive or negative direction of movement, this is also reported via ↪ *'0x8100-02 - Status word'* page 122. The module monitors the internally generated position set point and actual value. This deviation is called "Lag error". If the lag error exceeds the configurable limit value, there is an error reaction of the motion module, which can be configured.
- Velocity monitoring** The motion module monitors the velocity. The set velocity is limited to a configurable value and with active limitation reported via ↪ *'0x8100-02 - Status word'* page 122. When the value of the actual velocity exceeds the maximum permissible motor velocity ↪ *'0x8C00-07 - Motor max. velocity'* page 154, this is reported via the ↪ *'0x8100-02 - Status word'* page 122 and there is an error reaction of the motion module, which can be configured.
- Error reaction** The following errors can trigger an error reaction:
- Error max. velocity exceeded  
↪ *'0x8500-02 - Velocity control actual value'* page 140 > ↪ *'0x8C00-07 - Motor max. velocity'* page 154
  - Error lag error  
↪ *'0x8480-10 - Lag error'* page 138 > ↪ *'0x8480-12 - Lag error error'* page 139
  - Temperature error  $\mu$ -Controller  
↪ *'0x8780-02 - Temperature  $\mu$ -Controller actual value'* page 151 > ↪ *'0x8780-04 - Temperature  $\mu$ -Controller error level'* page 152
  - Temperature error power stage motion module  
↪ *'0x8780-07 - Temperature power stage actual value'* page 152 > ↪ *'0x8780-09 - Temperature power stage error level'* page 153
  - Error system communication timeout  
↪ *'0x6100-10 - System message timeout maximum'* page 115
  - Error command output disable (BASP)
- On error, the motion module starts an error reaction. The error reaction can be configured. Here you have the following possibilities:
- Immediate state change to *'Switch on disabled'*.
  - Break with quick stop deceleration ↪ *'0x8580-03 - Deceleration quick stop value'* page 143 and subsequent state change to *'Switch on disabled'*.

## 4.15.2 Monitoring



### Access to 2 drives

For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.

- Object dictionary drive 1: 0x8000 ... 0x8FFF
- Object dictionary drive 2: 0x9000 ... 0x9FFF


### Monitoring limitation

↳ '0x8400-02 - Positioning profile target position' page 135	→	Monitoring Limitation	→	↳ '0x8100-02 - Status word' page 122
↳ '0x8480-02 - Position actual value' page 136				
↳ '0x8480-05 - Software position limit positive direction' page 137				
↳ '0x8480-06 - Software position limit negative direction' page 137				
↳ '0x8400-03 - Positioning profile target velocity' page 135				
↳ '0x8500-04 - Velocity control limit positive direction' page 141				
↳ '0x8500-05 - Velocity control limit negative direction' page 141				
↳ '0x8600-03 - Current target value' page 144				
↳ '0x8600-04 - Current limit positive direction' page 145				
↳ '0x8600-05 - Current limit negative direction' page 145				↳ '0x8100-04 - Limit active bits' page 125

**Monitoring warning**

<p>↳ '0x8680-02 - Power section supply voltage actual value' page 149</p>	→	Monitoring Warning	→	<p>↳ '0x8100-02 - Status word' page 122</p>
<p>↳ '0x8680-04 - Power section supply voltage min. warning level' page 149</p>				
<p>↳ '0x8680-05 - Power section supply voltage max. warning level' page 149</p>				
<p>↳ '0x8680-08 - Control voltage power stage actual value' page 150</p>				
<p>↳ '0x8680-10 - Control voltage power stage min. warning level' page 150</p>				
<p>↳ '0x8680-11 - Control voltage power stage max. warning level' page 150</p>				
<p>↳ '0x8780-02 - Temperature <math>\mu</math>-Controller actual value' page 151</p>				<p>↳ '0x8100-05 - Warnings active bits' page 126</p>
<p>↳ '0x8780-03 - Temperature <math>\mu</math>-Controller warning level' page 152</p>				
<p>↳ '0x8780-07 - Temperature power stage actual value' page 152</p>				
<p>↳ '0x8780-08 - Temperature power stage warning level' page 152</p>				
<p>↳ '0x8480-10 - Lag error' page 138</p>				

**Monitoring errors**



**Error status - Monitoring errors**

<ul style="list-style-type: none"> <li>↳ '0x8680-02 - Power section supply voltage actual value' page 149</li> <li>↳ '0x8680-06 - Power section supply voltage min. error level' page 149</li> <li>↳ '0x8680-07 - Power section supply voltage max. error level' page 150</li> <li>↳ '0x8680-08 - Control voltage power stage actual value' page 150</li> <li>↳ '0x8680-12 - Control voltage power stage min. error level' page 151</li> <li>↳ '0x8680-13 - Control voltage power stage max. error level' page 151</li> <li>↳ '0x8780-02 - Temperature μ-Controller actual value' page 151</li> <li>↳ '0x8780-04 - Temperature μ-Controller error level' page 152</li> <li>↳ '0x8780-07 - Temperature power stage actual value' page 152</li> <li>↳ '0x8780-09 - Temperature power stage error level' page 153</li> <li>↳ '0x8480-10 - Lag error' page 138</li> <li>↳ '0x8500-02 - Velocity control actual value' page 140</li> <li>↳ '0x8600-10 - Current actual value winding A' page 146</li> <li>↳ '0x8C00-04 - Motor max. current' page 153</li> </ul>	<p>→</p>	<p>■ Error status Monitoring errors</p>	<p>→</p>	<ul style="list-style-type: none"> <li>■ Error response Error reaction</li> <li>↳ '0x8100-06 - Error active bits' page 127</li> <li>↳ '0x8100-03 - Error code' page 123</li> <li>↳ '0x8100-02 - Status word' page 122</li> </ul>
---	----------	---	----------	--

**Error response - error reaction**

<ul style="list-style-type: none"> <li>■ Error status Monitoring errors</li> <li>↳ '0x8200-05 - Configuration fault reaction' page 129</li> <li>↳ '0x8580-03 - Deceleration quick stop value' page 143</li> </ul>	<p>→</p>	<p>■ Error response Configuration reaction</p>	<p>→</p>	<ul style="list-style-type: none"> <li>↳ '0x8100-02 - Status word' page 122</li> </ul>
---	----------	--	----------	--

## 4.16 Diagnostics and interrupt

### Diagnostic data

Via the parametrization you may activate a diagnostic interrupt for the module. With a diagnostics interrupt the module serves for diagnostics data for diagnostic interrupt<sub>incoming</sub>. As soon as the reason for releasing a diagnostic interrupt is no longer present, the diagnostic interrupt<sub>going</sub> automatically takes place. Within this time window (1. diagnostic interrupt<sub>incoming</sub> until last diagnostic interrupt<sub>going</sub>) the MF-LED of the module is on.

DS - Record set for access via CPU, PROFIBUS and PROFINET. The access happens by DS 01h. Additionally the first 4 bytes may be accessed by DS 00h.

IX - Index for access via CANopen. The access happens by IX 2F01h. Additionally the first 4 bytes may be accessed by IX 2F00h.

SX - Subindex for access via EtherCAT with Index 5005h.

More can be found in the according manual of your bus coupler.

Name	Bytes	Function	Default	DS	IX	SX
ERR_A	1	Diagnostic	00h	01h	2F01h	02h
MODTYP	1	Module information	18h			03h
ERR_C	1	reserved	00h			04h
ERR_D	1	reserved	00h			05h
CHTYP	1	Channel type	72h			06h
NUMBIT	1	Number diagnostics bits per channel	08h			07h
NUMCH	1	Number channels of the module	04h			08h
CHERR	1	Channel error	00h			09h
CH0ERR	1	Channel-specific error	00h			0Ah
CH1ERR	1	Channel-specific error	00h			0Bh
CH2ERR	1	Channel-specific error	00h			0Ch
CH3ERR	1	Channel-specific error	00h			0Dh
CH4ERR... CH7ERR	4	reserved	00h			0Eh ... 11h
DIAG_US	4	µs ticker (32bit)	00h			13h

### ERR\_A Diagnostic

Byte	Bit 7 ... 0
0	<ul style="list-style-type: none"> <li>■ Bit 0: set at module failure</li> <li>■ Bit 1: set at internal error</li> <li>■ Bit 2: set at external error</li> <li>■ Bit 3: set at channel error</li> <li>■ Bit 6 ... 4: reserved</li> <li>■ Bit 7: set at error in parametrization</li> </ul>

**MODTYP Module information**

Byte	Bit 7 ... 0
0	<ul style="list-style-type: none"> <li>■ Bit 3 ... 0: Module class               <ul style="list-style-type: none"> <li>– 1000b: Function module</li> </ul> </li> <li>■ Bit 4: set at channel information present</li> <li>■ Bit 7 ... 5: reserved</li> </ul>

**CHTYP Channel type**

Byte	Bit 7 ... 0
0	<ul style="list-style-type: none"> <li>■ Bit 6 ... 0: Channel type               <ul style="list-style-type: none"> <li>– 72h: Digital output</li> </ul> </li> <li>■ Bit 7: 0 (fix)</li> </ul>

**NUMBIT Diagnostic bits**

Byte	Bit 7 ... 0
0	Number of diagnostic bits per channel (here 08h)

**NUMCH Channels**

Byte	Bit 7 ... 0
0	Number of channels of a module (here 04h)

**CHERR - Channel error**

Byte	Bit 7 ... 0
0	<ul style="list-style-type: none"> <li>■ Bit 0: set on error output I/O1</li> <li>■ Bit 1: set on error output I/O2</li> <li>■ Bit 2: set on error output I/O3</li> <li>■ Bit 3: set on error output I/O4</li> <li>■ Bit 7 ... 4: reserved</li> </ul>

**CH0ERR...CH3ERR channel specific**

Byte	Bit 7 ... 0
0	Diagnostics interrupt due to ... <ul style="list-style-type: none"> <li>■ Bit 2 ... 0: reserved</li> <li>■ Bit 3: Short circuit</li> <li>■ Bit 7 ... 4: reserved</li> </ul>

**DIAG\_US  $\mu$ s ticker**

Byte	Bit 7 ... 0
0 ... 3	Value $\mu$ s ticker at the moment of the diagnostic

**ERR\_C/D, CH4ERR ... CH7ERR reserved**

Byte	Bit 7 ... 0
0	reserved

Use

## 5 Object dictionary

### 5.1 Use

#### Addressing

The System SLIO motion module provides its data, such as "Profiling target position" via an object dictionary. In this object dictionary the objects are organized and addressable a unique number consisting of *Index* and *Subindex*. The number is specified as follows:

0x	Index (hexadecimal)	-	Subindex (decimal)
Example: 0x8400-03			



*To improve the structure and for expansion at System SLIO Motion Module another object numbering (index-assignment) is used besides the standard CiA 402.*

#### Index area

By separating into index and subindex a grouping is possible. The individual areas are divided into groups of related objects. With the System SLIO motion module this object directory is structured as follows:

Index area	Content
0x1000 ... 0x6FFF	General data and system data
0x7000 ... 0x7FFF	Data of the digital input and output part
0x8000 ... 0x8FFF	Data drive 1
0x9000 ... 0x9FFF	Data drive 2



*Each object has a subindex 0. Calling an object with subindex 0, the number of available subindexes of the corresponding object is returned.*



*In the manual, the index ranges of drive 1 (0x8000 ... 0x8FFF) are described. For drive 2 this corresponds to the index range 0x9000 ... 0x9FFF.*



**Accessing the object dictionary**

The communication takes place via the I/O area. The main data of the object dictionary are mapped into the I/O area. ↪ *Chap. 4.11 'In-/Output area' page 95*

Included in the mapping is also the *Acyclic Channel* through which you can acyclically access the objects of the motion module. With the acyclic access, any access to the object dictionary is acknowledged by the motion module. ↪ *Chap. 4.12 'Acyclic channel' page 98*

The mapping cannot be changed.



*Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.*

**5.2 Objects****5.2.1 Overview****Access to 2 drives**

*For each drive, there is an object dictionary whose structures are identical. Please note that the descriptions always relate to drive 1, unless otherwise noted. To access drive 2, you have to add 0x1000 to the corresponding object.*

- Object dictionary drive 1: 0x8000 ... 0x8FFF
- Object dictionary drive 2: 0x9000 ... 0x9FFF

**Explanation of the elements**

Explanation of the elements

Index-Sub - Index and subindex

Sx - Data type SIGNEDx

Ux - Data type UNSIGNEDx

STG - Data type STRING

RW - Read- write access

[degC] - Temperature in degree celsius (°C)

[inc] - Increment - pulse of an encoder

[User] - The unit [User] is a user defined unit, which can be set via ↪ *'0x8180-02 - Gear factor' page 128.*

\* - Object, which is mapped in the ↪ *Chap. 4.11 'In-/Output area' page 95.* If you write via the *Acyclic Channel* to this object, the value is overwritten with the next cycle.

\*\* - Object, which can be written in all states of the state machine. Otherwise objects can only be written in the state *'Switch on disabled'*. ↪ *'Accessing the state machine' page 64*

↪ *Chap. 5.2.3 'Passwords and security - 0x1100' page 114*

**Available objects**

- [🔗 '0x1000-00 - Device type' page 113](#)
- [🔗 '0x1008-00 - Manufacturer device name' page 113](#)
- [🔗 '0x100A-00 - Manufacturer software version' page 113](#)
- [🔗 '0x1018-00 - Product - number of entries' page 113](#)
- [🔗 '0x1018-02 - Product ID' page 114](#)
- [🔗 '0x1018-03 - Revision number' page 114](#)
- [🔗 '0x1018-04 - Serial number' page 114](#)
- [🔗 '0x1018-05 - Module category' page 114](#)
- [🔗 '0x1100-00 - Passwords and security - number of entries' page 114](#)
- [🔗 '0x1100-01 - Password' page 115](#)
- [🔗 '0x6100-00 - System command - number of entries' page 115](#)
- [🔗 '0x6100-10 - System message timeout maximum' page 115](#)
- [🔗 '0x7100-00 - Digital inputs - number of entries' page 115](#)
- [🔗 '0x7100-01...04 - Digital input configuration I/O1...I/O4' page 116](#)
- [🔗 '0x7100-05 - Digital input states I/O1...I/O4' page 117](#)
- [🔗 '0x7200-00 - Digital outputs - number of entries' page 117](#)
- [🔗 '0x7200-01...04 - Digital output configuration I/O1...I/O4' page 118](#)
- [🔗 '0x7200-05 - Digital output states I/O1...I/O4 actual states' page 119](#)
- [🔗 '0x7200-06 - Digital output states I/O1...I/O4 requested states' page 120](#)
- [🔗 '0x8100-00 - Control drive - number of entries' page 120](#)
- [🔗 '0x8100-01 - Control word' page 121](#)
- [🔗 '0x8100-02 - Status word' page 122](#)
- [🔗 '0x8100-03 - Error code' page 123](#)
- [🔗 '0x8100-04 - Limit active bits' page 125](#)
- [🔗 '0x8100-05 - Warnings active bits' page 126](#)
- [🔗 '0x8100-06 - Error active bits' page 127](#)
- [🔗 '0x8180-00 - Configure drive - number of entries' page 128](#)
- [🔗 '0x8180-02 - Gear factor' page 128](#)
- [🔗 '0x8200-00 - Options - number of entries' page 129](#)
- [🔗 '0x8200-01 - Configuration quick stop' page 129](#)
- [🔗 '0x8200-05 - Configuration fault reaction' page 129](#)
- [🔗 '0x8280-00 - Operating mode - number of entries' page 130](#)
- [🔗 '0x8280-01 - Operating mode requested' page 130](#)
- [🔗 '0x8280-02 - Operating mode actual' page 131](#)
- [🔗 '0x8300-00 - Homing - number of entries' page 131](#)
- [🔗 '0x8300-02 - Homing method' page 131](#)
- [🔗 '0x8300-03 - Homing digital input I/O1...I/O4' page 132](#)
- [🔗 '0x8300-04 - Homing digital input active polarity I/O1...I/O4' page 132](#)
- [🔗 '0x8300-05 - Homing target position' page 133](#)
- [🔗 '0x8300-06 - Homing velocity V1' page 133](#)

- [🔗 '0x8300-07 - Homing velocity V2' page 133](#)
- [🔗 '0x8300-08 - Homing acceleration' page 134](#)
- [🔗 '0x8300-09 - Homing deceleration' page 134](#)
- [🔗 '0x8300-10 - Homing offset value' page 134](#)
- [🔗 '0x8300-12 - Homing trq mode current' page 134](#)
- [🔗 '0x8300-13 - Homing trq mode distance' page 135](#)
- [🔗 '0x8400-00 - Positioning profile - number of entries' page 135](#)
- [🔗 '0x8400-02 - Positioning profile target position' page 135](#)
- [🔗 '0x8400-03 - Positioning profile target velocity' page 135](#)
- [🔗 '0x8400-04 - Positioning profile target acceleration' page 136](#)
- [🔗 '0x8400-05 - Positioning profile target deceleration' page 136](#)
- [🔗 '0x8480-00 - Positions and limits - number of entries' page 136](#)
- [🔗 '0x8480-02 - Position actual value' page 136](#)
- [🔗 '0x8480-03 - Target position' page 137](#)
- [🔗 '0x8480-05 - Software position limit positive direction' page 137](#)
- [🔗 '0x8480-06 - Software position limit negative direction' page 137](#)
- [🔗 '0x8480-07 - Range limit positive direction' page 138](#)
- [🔗 '0x8480-08 - Range limit negative direction' page 138](#)
- [🔗 '0x8480-09 - In-position window' page 138](#)
- [🔗 '0x8480-10 - Lag error' page 138](#)
- [🔗 '0x8480-11 - Lag error warning' page 139](#)
- [🔗 '0x8480-12 - Lag error error' page 139](#)
- [🔗 '0x8480-13 - Position control P-part' page 139](#)
- [🔗 '0x8480-14 - Position control I-part' page 139](#)
- [🔗 '0x8480-15 - Position control D-part' page 139](#)
- [🔗 '0x8480-16 - Position control shift factor' page 140](#)
- [🔗 '0x8500-00 - Velocity - number of entries' page 140](#)
- [🔗 '0x8500-01 - Velocity control configuration' page 140](#)
- [🔗 '0x8500-02 - Velocity control actual value' page 140](#)
- [🔗 '0x8500-03 - Velocity control target value' page 141](#)
- [🔗 '0x8500-04 - Velocity control limit positive direction' page 141](#)
- [🔗 '0x8500-05 - Velocity control limit negative direction' page 141](#)
- [🔗 '0x8500-06 - Velocity control range for torque limit' page 141](#)
- [🔗 '0x8500-07 - Velocity control limit type for torque mode' page 142](#)
- [🔗 '0x8500-11 - Velocity control P-part' page 142](#)
- [🔗 '0x8500-12 - Velocity control I-part' page 142](#)
- [🔗 '0x8500-13 - Velocity control D-part' page 142](#)
- [🔗 '0x8580-00 - Acceleration and deceleration - number entries' page 143](#)
- [🔗 '0x8580-02 - Acceleration/Deceleration actual value' page 143](#)
- [🔗 '0x8580-03 - Deceleration quick stop value' page 143](#)
- [🔗 '0x8580-04 - Acceleration limit' page 143](#)

- [🔗 '0x8580-06 - Deceleration limit' page 144](#)
- [🔗 '0x8600-00 - CUR current number of entries ' page 144](#)
- [🔗 '0x8600-02 - Current actual value' page 144](#)
- [🔗 '0x8600-03 - Current target value' page 144](#)
- [🔗 '0x8600-04 - Current limit positive direction' page 145](#)
- [🔗 '0x8600-05 - Current limit negative direction' page 145](#)
- [🔗 '0x8600-06 - Current control P-part' page 145](#)
- [🔗 '0x8600-07 - Current control I-part' page 145](#)
- [🔗 '0x8600-09 - Current control filter factor ' page 146](#)
- [🔗 '0x8600-10 - Current actual value winding A' page 146](#)
- [🔗 '0x8600-12 - Current target value winding A' page 146](#)
- [🔗 '0x8600-14 - Current offset value winding A' page 147](#)
- [🔗 '0x8600-16 - Current voltage ratio winding A' page 148](#)
- [🔗 '0x8680-00 - Voltages - number of entries' page 148](#)
- [🔗 '0x8680-02 - Power section supply voltage actual value' page 149](#)
- [🔗 '0x8680-04 - Power section supply voltage min. warning level' page 149](#)
- [🔗 '0x8680-05 - Power section supply voltage max. warning level' page 149](#)
- [🔗 '0x8680-06 - Power section supply voltage min. error level' page 149](#)
- [🔗 '0x8680-07 - Power section supply voltage max. error level' page 150](#)
- [🔗 '0x8680-08 - Control voltage power stage actual value' page 150](#)
- [🔗 '0x8680-10 - Control voltage power stage min. warning level' page 150](#)
- [🔗 '0x8680-11 - Control voltage power stage max. warning level' page 150](#)
- [🔗 '0x8680-12 - Control voltage power stage min. error level' page 151](#)
- [🔗 '0x8680-13 - Control voltage power stage max. error level' page 151](#)
- [🔗 '0x8780-00 - Temperatures - number of entries' page 151](#)
- [🔗 '0x8780-02 - Temperature  \$\mu\$ -Controller actual value' page 151](#)
- [🔗 '0x8780-03 - Temperature  \$\mu\$ -Controller warning level' page 152](#)
- [🔗 '0x8780-04 - Temperature  \$\mu\$ -Controller error level' page 152](#)
- [🔗 '0x8780-07 - Temperature power stage actual value' page 152](#)
- [🔗 '0x8780-08 - Temperature power stage warning level' page 152](#)
- [🔗 '0x8780-09 - Temperature power stage error level' page 153](#)
- [🔗 '0x8C00-00 - Motor data - number of entries' page 153](#)
- [🔗 '0x8C00-04 - Motor max. current' page 153](#)
- [🔗 '0x8C00-06 - Motor nominal velocity' page 153](#)
- [🔗 '0x8C00-07 - Motor max. velocity' page 154](#)
- [🔗 '0x8C00-09 - Motor velocity constant' page 154](#)
- [🔗 '0x8C00-10 - Motor phase resistance' page 154](#)
- [🔗 '0x8F00-00 - Encoder - number of entries' page 154](#)
- [🔗 '0x8F00-01 - Encoder Feedback configuration' page 155](#)
- [🔗 '0x8F00-02 - Encoder actual value' page 155](#)
- [🔗 '0x8F00-03 - Encoder resolution' page 156](#)



Objects &gt; Passwords and security - 0x1100

**0x1018-02 - Product ID**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1018-02	U32	R	0x534C494F	0 ... 0xFFFFFFFF		Product ID

↳ 'Explanation of the elements' page 109

Here according to CiA 402 the product ID of the motion module can be found:  
0x534C494F

**0x1018-03 - Revision number**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1018-03	U32	R	0	0 ... 0xFFFFFFFF		Revision number

↳ 'Explanation of the elements' page 109

Here according to CiA 402 the revision number of the module can be found. Currently this object is not used and returns 0.

**0x1018-04 - Serial number**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1018-04	U32	R	0	0 ... 0xFFFFFFFF		Serial number

↳ 'Explanation of the elements' page 109

Here according to CiA 402 the serial number of the module can be found. Currently this object is not used and returns 0.

**0x1018-05 - Module category**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1018-05	U32	R	0	0 ... 200		Module category

↳ 'Explanation of the elements' page 109

Here according to CiA 402 you can find the module category of the motion module: 0x31:  
DCM

**5.2.3 Passwords and security - 0x1100****0x1100-00 - Passwords and security - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1100-00	U08	R	2	2		Passwords and security - number of entries

↳ 'Explanation of the elements' page 109

**0x1100-01 - Password**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x1100-01	U32	R/W**	0	0 ... 0xFFFFFFFF		Password

↳ 'Explanation of the elements' page 109

With this object you can enable the password, which allows to write objects in all states of the state machine. Otherwise objects can only be written in the state 'Switch on disabled'. The password is: 0xABCDABCD and cannot be changed. ↳ 'Accessing the state machine' page 64

**5.2.4 System command - 0x6100****0x6100-00 - System command - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x6100-00	U08	R	17	17		System command - number of entries

↳ 'Explanation of the elements' page 109

**0x6100-10 - System message timeout maximum**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x6100-10	U32	R/W	0	0 ... 0xFFFFFFFF	[mS]	System message timeout maximum

↳ 'Explanation of the elements' page 109

With this object, you can enable the monitoring of the cyclic communication to the System SLIO bus and thus to the fieldbus. If there is no communication within the specified time in ms, the motion module enters the error state. Should the application require a cyclic communication with the motion module but the monitoring of the cycle can not be ensured on the side of the fieldbus coupler or CPU, by means of this object a monitoring time should be entered. By default, no monitoring is active.

**5.2.5 Digital inputs I/O1...I/O4 - 0x7100****0x7100-00 - Digital inputs - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7100-00	U08	R	7	7		Digital inputs - number of entries

↳ 'Explanation of the elements' page 109

↳ Chap. 4.9 'Deployment I/O1...I/O4' page 91

### 0x7100-01...04 - Digital input configuration I/O1...I/O4

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7100-00	U08	R	7	7		Digital inputs - number of entries
0x7100-01	U08	R/W**	1	0 ... 1		Digital input configuration I/O1
0x7100-02	U08	R/W**	1	0 ... 1		Digital input configuration I/O2
0x7100-03	U08	R/W**	1	0 ... 1		Digital input configuration I/O3
0x7100-04	U08	R/W**	1	0 ... 1		Digital input configuration I/O4

↳ 'Explanation of the elements' page 109

With these objects, the four digital inputs/outputs I/O1...I/O4 are configured as inputs.

- 0: The I/Ox is used as digital output
  - DC 24V
  - 500 mA
  - High-side (source)
- 1: The I/Ox is used as digital input
  - DC 24V
  - IEC 61131-2 Typ 3
  - High-side (sink)
  - The configuration as encoder happens via ↳ '0x8F00-01 - Encoder Feedback configuration' page 155
- The inputs can always be read, so its configuration is independent of the configuration as outputs (object 0x7200-01 ... -04).
- If a digital input/output is defined as output via object 0x7200, it can be read via the cyclic data *Status DO*. It is the really pending state at the digital driver part and not set point value, generated by the cyclic data *Status DI* or system.



**0x7100-05 - Digital input states I/O1...I/O4**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7100-05*	U08	R	0	0 ... 0xFF		Digital input states I/O1...I/O4

↳ 'Explanation of the elements' page 109

This object contains the current values of the digital inputs I/O1...I/O4. They also can be found in the I/O area.



Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.

**Bit 3 ... 0**

3	2	1	0	Description
x	x	x	0	Input I/O1 has signal "0"
x	x	x	1	Input I/O1 has signal "1"
x	x	0	x	Input I/O2 has signal "0"
x	x	1	x	Input I/O2 has signal "1"
x	0	x	x	Input I/O3 has signal "0"
x	1	x	x	Input I/O3 has signal "1"
0	x	x	x	Input I/O4 has signal "0"
1	x	x	x	Input I/O4 has signal "1"

**5.2.6 Digital output I/O1...I/O4 - 0x7200****0x7200-00 - Digital outputs - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7200-00	U08	R	6	6		Digital outputs - number of entries

↳ 'Explanation of the elements' page 109

↳ Chap. 4.9 'Deployment I/O1...I/O4' page 91

Objects &gt; Digital output I/O1...I/O4 - 0x7200

**0x7200-01...04 - Digital output configuration I/O1...I/O4**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7200-01	U08	R/W**	0	0 ... 1		Digital output configuration I/O1
0x7200-02	U08	R/W**	0	0 ... 1		Digital output configuration I/O2
0x7200-03	U08	R/W**	0	0 ... 1		Digital output configuration I/O3
0x7200-04	U08	R/W**	0	0 ... 1		Digital output configuration I/O4

↪ 'Explanation of the elements' page 109

With these objects, the four digital inputs/outputs I/O1...I/O4 are configured as outputs. If a digital input/output is defined as output, it can be read via the cyclic data. This is the really pending state at the digital driver part.

Value	Description
0	The output is de-activated.
1	The output is activated and can be controlled by the cyclic data ↪ '0x7200-06 - Digital output states I/O1...I/O4 requested states' page 120.

**0x7200-05 - Digital output states I/O1...I/O4 actual states**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7200-05*	U08	R	0	0 ... 0xFF		Digital output states I/O1...I/O4 actual states

[↩ 'Explanation of the elements' page 109](#)

This object contains the current values of the digital outputs. They also can be found in the I/O area.



*Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.*

**Bit 3 ... 0**

3	2	1	0	Description
x	x	x	0	I/O1 has signal "0"
x	x	x	1	I/O1 has signal "1"
x	x	0	x	I/O2 has signal "0"
x	x	1	x	I/O2 has signal "1"
x	0	x	x	I/O3 has signal "0"
x	1	x	x	I/O3 has signal "1"
0	x	x	x	I/O4 has signal "0"
1	x	x	x	I/O4 has signal "1"

Objects &gt; Driver command - 0x8100

### 0x7200-06 - Digital output states I/O1...I/O4 requested states

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x7200-06*	U08	R/W**	0	0 ... 0xFF		Digital output states I/O1...I/O4 requested states

[↪ 'Explanation of the elements' page 109](#)

This object contains the set values of the digital outputs I/O1...I/O4. They also can be found in cyclic data in the I/O area.



Please note if you write via the Acyclic Channel to objects, which are mapped in the I/O area, these values are overwritten with the next cycle.

#### Bit 3 ... 0

3	2	1	0	Description
x	x	x	0	Output I/O1 has signal "0"
x	x	x	1	Output I/O1 has signal "1"
x	x	0	x	Output I/O2 has signal "0"
x	x	1	x	Output I/O2 has signal "1"
x	0	x	x	Output I/O3 has signal "0"
x	1	x	x	Output I/O3 has signal "1"
0	x	x	x	Output I/O4 has signal "0"
1	x	x	x	Output I/O4 has signal "1"

## 5.2.7 Driver command - 0x8100

### 0x8100-00 - Control drive - number of entries

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-00	U08	R	6	6		Control drive - number of entries

[↪ 'Explanation of the elements' page 109](#)

**0x8100-01 - Control word**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-01*	U16	R/W**	0	0 ... 65535		Control word

↳ 'Explanation of the elements' page 109

↳ Chap. 4.4.2 'States' page 63

With the *Control word* you can change the current state of the motor controller respectively reset all the error bits.

**Bit 3 ... 0 - Control drive state**

3	2	1	0	Description
x	1	1	0	Shutdown
0	1	1	1	Switch on
1	1	1	1	Switch on and enable operation
x	x	0	x	Disable voltage
0	1	1	1	Disable operation
1	1	1	1	Enable operation
x	0	1	x	Quick stop

**Bit 15 ... 4 - Reset error bits**

15...8	7	6	Description
reserved	0→1	reserved	Edge 0-1 resets all error bits in ↳ '0x8100-06 - Error active bits' page 127.

**0x8100-02 - Status word**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-02*	U16	R	0	0 ... 65535		Status word

↳ 'Explanation of the elements' page 109

↳ Chap. 4.4.2 'States' page 63



Please consider that the data bits are not latched and may need to be temporarily stored for further processing!

**Bit 7 ... 0 - Control drive state**

7	6	5	4	3	2	1	0	Description
x	0	x	x	0	0	0	0	State 'Not ready to switch on'
x	1	x	x	0	0	0	0	State 'Switch on disabled'
x	0	1	x	0	0	0	1	State 'Ready to switch on'
x	0	1	x	0	0	1	1	State 'Switched on'
x	0	1	x	0	1	1	1	State 'Operation enabled'
x	0	0	x	0	1	1	1	State 'Quick stop active'
x	0	x	x	1	1	1	1	State 'Fault reaction active'
x	0	x	x	1	0	0	0	State 'Error' ↳ '0x8100-03 - Error code' page 123
1	x	x	x	x	x	x	x	A warning has occurred ↳ '0x8100-05 - Warnings active bits' page 126

**Bit 15 ... 8 - Operating mode state**

15	14	13	12	11	10	9	8	Description
x	x	x	x	x	0	x	x	Target position not reached (axis is stopped)
x	x	x	x	x	1	x	x	Target position reached (axis velocity = 0)
x	x	x	x	0	x	x	x	There is no internal limitation
x	x	x	x	1	x	x	x	There is an internal limitation The type of limitation depends on the operating mode.

**0x8100-03 - Error code**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-03	U16	R	0	0 ... 65535		Error code

↳ *'Explanation of the elements' page 109*

↳ *Chap. 4.15 'Monitoring and error reaction' page 101*

This object shows the most recent error code, which has occurred in the System SLIO motion module. A group message can be obtained from bit 3 in the ↳ *'0x8100-02 - Status word' page 122*.

There are the following error messages:

**Error**

Code	Description
0x2310	Permanent internal short circuit ↳ <i>'0x8600-10 - Current actual value winding A' page 146</i> is greater than ↳ <i>'0x8C00-04 - Motor max. current' page 153</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 0
0x2340	Short-circuit in motor ↳ <i>'Connections' page 47</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 1
0x3210	Power section supply overvoltage ↳ <i>'0x8680-07 - Power section supply voltage max. error level' page 150</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 17
0x3220	Power section supply reduced voltage ↳ <i>'0x8680-12 - Control voltage power stage min. error level' page 151</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 16
0x4310	Temperature $\mu$ -controller exceeded ↳ <i>'0x8780-04 - Temperature <math>\mu</math>-Controller error level' page 152</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 12, 13
0x5115	Control voltage power stage exceeds the range of values. ↳ <i>'0x8680-12 - Control voltage power stage min. error level' page 151</i> ↳ <i>'0x8680-13 - Control voltage power stage max. error level' page 151</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 18, 19
0x8400	Error in velocity control - please check you parameters. ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 4
0x8611	Error in position control - please check you parameters. ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 8
0xF001	Error encoder feedback control - please check you parameters. ↳ <i>Chap. 4.9.2.2 'Encoder - deployment' page 93</i> ↳ <i>'0x8100-06 - Error active bits' page 127</i> Bit: 20

Objects &gt; Driver command - 0x8100

Code	Description
0xF010	System communication timeout <a href="#">↪ '0x6100-10 - System message timeout maximum' page 115</a> <a href="#">↪ '0x8100-06 - Error active bits' page 127 Bit: 22</a>
0xF011	Command output disable (BASP) is active. <a href="#">↪ '0x8100-06 - Error active bits' page 127 Bit: 23</a>
0xF020	Error operation mode is not supported. <a href="#">↪ '0x8280-01 - Operating mode requested' page 130</a> <a href="#">↪ '0x8100-06 - Error active bits' page 127 Bit: 24</a>
0xF080	There is an internal error - please contact our support! <a href="#">↪ '0x8100-06 - Error active bits' page 127 Bit: 28</a>



**0x8100-04 - Limit active bits**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-04	U32	R	0	0 ... 0xFFFFFFFF		Limit active bits

0: de-activated, 1: activated

- Bit 0: Limitation current
  - [↪ '0x8600-03 - Current target value' page 144](#) > [↪ '0x8600-04 - Current limit positive direction' page 145](#)
  - [↪ '0x8600-03 - Current target value' page 144](#) < [↪ '0x8600-05 - Current limit negative direction' page 145](#)
- Bit 3 ... 1: reserved
- Bit 4: Limitation velocity
  - [↪ '0x8500-03 - Velocity control target value' page 141](#) > [↪ '0x8500-04 - Velocity control limit positive direction' page 141](#)
  - [↪ '0x8500-03 - Velocity control target value' page 141](#) < [↪ '0x8500-05 - Velocity control limit negative direction' page 141](#)
- Bit 7 ... 5: reserved
- Bit 8: Location of the set point position
  - 0: Position is out of the permissible limits
  - 1: Position is within the permissible limits
  - [↪ '0x8400-02 - Positioning profile target position' page 135](#) > [↪ '0x8480-05 - Software position limit positive direction' page 137](#)
  - [↪ '0x8400-02 - Positioning profile target position' page 135](#) < [↪ '0x8480-06 - Software position limit negative direction' page 137](#)
  - [↪ '0x8480-03 - Target position' page 137](#) > [↪ '0x8480-05 - Software position limit positive direction' page 137](#)
  - [↪ '0x8480-03 - Target position' page 137](#) < [↪ '0x8480-06 - Software position limit negative direction' page 137](#)
- Bit 9: Location of the current position
  - 0: Position is out of the permissible limits
  - 1: Position is within the permissible limits
  - [↪ '0x8480-02 - Position actual value' page 136](#) > [↪ '0x8480-05 - Software position limit positive direction' page 137](#)
  - [↪ '0x8480-02 - Position actual value' page 136](#) < [↪ '0x8480-06 - Software position limit negative direction' page 137](#)
- Bit 31 ... 10: reserved

[↪ 'Explanation of the elements' page 109](#)

[↪ Chap. 4.15 'Monitoring and error reaction' page 101](#)

Objects &gt; Driver command - 0x8100

**0x8100-05 - Warnings active bits**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-05	U32	R	0	0 ... 0xFFFFFFFF		Warnings active bits

0: de-activated, 1: activated

- Bit 7...0: reserved
- Bit 8: Warning lag error
  - [↗ '0x8480-10 - Lag error' page 138](#) > [↗ '0x8480-11 - Lag error warning' page 139](#)
- Bit 11...9: reserved
- Bit 12: Temperature warning  $\mu$ -Controller
  - [↗ '0x8780-02 - Temperature  \$\mu\$ -Controller actual value' page 151](#) > [↗ '0x8780-03 - Temperature  \$\mu\$ -Controller warning level' page 152](#)
- Bit 13: Temperature warning power stage motion module
  - [↗ '0x8780-07 - Temperature power stage actual value' page 152](#) > [↗ '0x8780-08 - Temperature power stage warning level' page 152](#)
- Bit 15, 14: reserved
- Bit 16: Warning under-voltage  $U_{IN}$  24V<sub>DC</sub>
  - [↗ '0x8680-02 - Power section supply voltage actual value' page 149](#) < [↗ '0x8680-04 - Power section supply voltage min. warning level' page 149](#)
- Bit 17: Warning over-voltage  $U_{IN}$  24V<sub>DC</sub>
  - [↗ '0x8680-02 - Power section supply voltage actual value' page 149](#) > [↗ '0x8680-05 - Power section supply voltage max. warning level' page 149](#)
- Bit 18: Warning under-voltage triggering power stage motion module
  - [↗ '0x8680-08 - Control voltage power stage actual value' page 150](#) < [↗ '0x8680-10 - Control voltage power stage min. warning level' page 150](#)
- Bit 19: Warning over-voltage triggering power stage motion module
  - [↗ '0x8680-08 - Control voltage power stage actual value' page 150](#) > [↗ '0x8680-11 - Control voltage power stage max. warning level' page 150](#)
- Bit 31...20: reserved

[↗ 'Explanation of the elements' page 109](#)[↗ Chap. 4.15 'Monitoring and error reaction' page 101](#)

**0x8100-06 - Error active bits**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8100-06	U32	R	0	0 ... 0xFFFFFFFF		Error active bits

0: de-activated, 1: activated

- Bit 0: Limit current error
  - [↪ '0x8600-10 - Current actual value winding A' page 146](#) > [↪ '0x8C00-04 - Motor max. current' page 153](#)
- Bit 1: Short circuit on the motor (phase current > 4A)
- Bit 3, 2: reserved
- Bit 4: Error max. velocity exceeded <sup>1)</sup>
  - [↪ '0x8500-02 - Velocity control actual value' page 140](#) > [↪ '0x8C00-07 - Motor max. velocity' page 154](#)
- Bit 7...5: reserved
- Bit 8: Error lag error <sup>1)</sup>
  - [↪ '0x8480-10 - Lag error' page 138](#) > [↪ '0x8480-12 - Lag error error' page 139](#)
- Bit 11...9: reserved
- Bit 12: Temperature error  $\mu$ -controller <sup>1)</sup>
  - [↪ '0x8780-02 - Temperature  \$\mu\$ -Controller actual value' page 151](#) > [↪ '0x8780-04 - Temperature  \$\mu\$ -Controller error level' page 152](#)
- Bit 13: Temperature error power stage motion module <sup>1)</sup>
  - [↪ '0x8780-07 - Temperature power stage actual value' page 152](#) > [↪ '0x8780-09 - Temperature power stage error level' page 153](#)
- Bit 15, 14: reserved
- Bit 16: Under-voltage U error<sub>IN</sub> 24V<sub>DC</sub>
  - [↪ '0x8680-02 - Power section supply voltage actual value' page 149](#) < [↪ '0x8680-06 - Power section supply voltage min. error level' page 149](#)
- Bit 17: Over-voltage U error<sub>IN</sub> 24V<sub>DC</sub>
  - [↪ '0x8680-02 - Power section supply voltage actual value' page 149](#) > [↪ '0x8680-07 - Power section supply voltage max. error level' page 150](#)
- Bit 18: Under-voltage triggering power stage error motion module
  - [↪ '0x8680-08 - Control voltage power stage actual value' page 150](#) < [↪ '0x8680-12 - Control voltage power stage min. error level' page 151](#)
- Bit 19: Over-voltage triggering power stage error motion module
  - [↪ '0x8680-08 - Control voltage power stage actual value' page 150](#) > [↪ '0x8680-13 - Control voltage power stage max. error level' page 151](#)
- Bit 20: Encoder system is not configured or faulty
  - ↪ ['0x8F00-01 - Encoder Feedback configuration' page 155](#) is not set to encoder mode (0x01)
- Bit 21: reserved
- Bit 22: Error system communication timeout <sup>1)</sup>
  - [↪ '0x6100-10 - System message timeout maximum' page 115](#)
- Bit 23: Error command output disable (BASP) active <sup>1)</sup>
- Bit 27 ... 24: reserved
- Bit 28: System error
  - There is an internal error - please contact our Yaskawa support!
- Bit 31...29: reserved

[↪ 'Explanation of the elements' page 109](#)

<sup>1)</sup> Triggers an error reaction [↪ Chap. 4.15 'Monitoring and error reaction' page 101](#)

## 5.2.8 Configure drive - 0x8180

### 0x8180-00 - Configure drive - number of entries

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8180-00	U08	R	3	3		Configure drive - number of entries
<a href="#">↪ 'Explanation of the elements' page 109</a>						

### 0x8180-02 - Gear factor

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8180-02	U32	R/W	10000000	800000 ... 16000000		Gear factor
<a href="#">↪ 'Explanation of the elements' page 109</a>						

Gear factor for normalization of position, velocity and acceleration values. The value represents "units" in thousands with the rotary axis makes exactly one revolution. "Units" may thus be regarded as user units such as  $\mu\text{m}$ , mm, inch, degree angle and revolutions.

- Position
  - A to be traversed position thus results directly from the specified number of units.
- Velocity
  - The velocity is normalized to unit/s
- Acceleration and deceleration
  - Acceleration and deceleration are normalized to  $\text{unit/s}^2$

#### Example 1:

A motor directly drives a toothed disk. Via a toothed belt, a drilling machine is 1:1 coupled. It is to be used with a resolution of 0.0001 U (= 1 unit). In order to drive a speed of 900 U/min, therefore, a value of 150000 must be reported.

$$\text{Units} = \frac{1U/U}{0.0001U} = 10000 \text{ } 1/U$$

$$\text{Gear factor} = 10000 \cdot 1000 = 10000000$$

#### Example 2:

A motor directly drives a spindle with a pitch of 20 mm/U. It is to be used with a resolution of 10  $\mu\text{m}$  (= 1 unit). In order to traverse a difference in position of 7000  $\mu\text{m}$ , 7000 can directly be specified (relative to the previous value).

$$\text{Units} = \frac{20\text{mm}/U}{10\mu\text{m}} = 20000 \text{ } 1/U$$

$$\text{Gear factor} = 20000 \cdot 1000 = 20000000$$

## 5.2.9 Options - 0x8200

### 0x8200-00 - Options - number of entries

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8200-00	U08	R	5	5		Options - number of entries

↳ 'Explanation of the elements' page 109

### 0x8200-01 - Configuration quick stop

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8200-01	S16	R/W**	2	-32768 ... 32767		Configuration quick stop

↳ 'Explanation of the elements' page 109

↳ Chap. 4.10 'Brake control' page 95

The object contains the action to be used at a *Quick stop*.

Mode	Description
0	Instant state change to ' <i>Switch on disabled</i> '
1	reserved
2	Break with quick stop deceleration 0x8580-03 and subsequent state change to ' <i>Switch on disabled</i> '
4...	reserved

### 0x8200-05 - Configuration fault reaction

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8200-05	S16	R/W**	2	0 ... 2		Configuration fault reaction

↳ 'Explanation of the elements' page 109

The object contains the action to be used on an error of the System SLIO motion module.

Mode	Description
0	Instant state change to ' <i>Switch on disabled</i> '
1	reserved
2	Break with 0x8580-03 and subsequent state change to ' <i>Switch on disabled</i> '
4...	reserved

Objects &gt; Operating modes - 0x8280

## 5.2.10 Operating modes - 0x8280

### 0x8280-00 - Operating mode - number of entries

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8280-00	U08	R	2	2		Operating mode - number of entries
🔗 'Explanation of the elements' page 109						

### 0x8280-01 - Operating mode requested

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8280-01*	S16	R/W	0	-128 ... 127		Operating mode requested
🔗 'Explanation of the elements' page 109						

With the object 0x8280-01 the mode of the motor controller can be set. The following operating modes are supported:

Value	Description
0	No operating mode
1	🔗 Chap. 4.6 'PtP positioning profile' page 72 <ul style="list-style-type: none"> <li>■ The <i>Homing mode</i> can be called during the operation, if you have previously set a homing method via 🔗 '0x8300-02 - Homing method' page 131.</li> <li>■ A change to the <i>Velocity profile</i> is only possible if the state machine is in state 'Switch on disabled'.</li> </ul>
3	🔗 Chap. 4.7 'Velocity profile' page 84
4	reserved
6	🔗 Chap. 4.5 'Homing' page 65
10	🔗 Chap. 4.8 'Torque control' page 88

**0x8280-02 - Operating mode actual**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8280-02*	S16	R	0	-128 ... 127		Operating mode actual

↳ *'Explanation of the elements' page 109*

In object 0x8280-02 the current operating mode of the motor controller can be read. The following values are supported:

Value	Description
0	No operating mode selected
-1	Invalid operating mode or operating mode change
1	↳ <i>Chap. 4.6 'PtP positioning profile' page 72</i>
3	↳ <i>Chap. 4.7 'Velocity profile' page 84</i>
4	reserved
6	↳ <i>Chap. 4.5 'Homing' page 65</i>
10	↳ <i>Chap. 4.8 'Torque control' page 88</i>

**5.2.11 Homing - 0x8300****0x8300-00 - Homing - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-00	U08	R	13	13		Homing - number of entries

↳ *'Explanation of the elements' page 109*

↳ *Chap. 4.5 'Homing' page 65*

**0x8300-02 - Homing method**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-02	S08	R/W**	0	-128 ... 127		Homing method

↳ *'Explanation of the elements' page 109*

↳ *Chap. 4.5 'Homing' page 65*

This object is used to select the homing method. Homing is an initialization drive of an axis, where the correct position is determined by means of a reference signal. For complete configuration of a homing run, all index 0x8300 associated objects are required.

**Supported homing method**

Mode	Description
-1	It is referenced in response to the current limitation. ↗ '0x8300-12 - Homing trq mode current' page 134
17	It is referenced to a switch at the end of the position area (= homing switch). For the evaluation of the reference switch, a digital input of the System SLIO motion module is used. A pulse signal is expected.
37	The current position is used as reference position and the position value is reset to zero.



Please note that neither homing nor other operation modes of System SLIO motion module are monitored by limit switches, which cause a shut-down or stopping when reached. If you wish a surveillance and response, you have to ensure this through separate measures.

**0x8300-03 - Homing digital input I/O1...I/O4**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-03	U08	R/W**	0	0 ... 4		Homing digital input I/O1...I/O4

↗ 'Explanation of the elements' page 109

This object sets for homing *Mode 17* the digital input I /O1 ... I /O4 to which the homing switch is connected.

Enter here number:

- 0: inactive
- 1: Input of DIO1
- 2: Input of DIO2
- 3: Input of DIO3
- 4: Input of DIO4

**0x8300-04 - Homing digital input active polarity I/O1...I/O4**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-04	U08	R/W**	1	0 ... 1		Homing digital input active polarity I/O1...I/O4

↗ 'Explanation of the elements' page 109

This object sets for homing *Mode 17* the polarity of the digital input I/O1...I/O4 of the System SLIO motion module. The internal logic of the System SLIO motion module evaluates a pulse signal from the reference switch. Please note in this case, the correct electrical connection!

Value	Description
0	The reference switch triggers a state change 1-0 at the end position.
1	The reference switch triggers a state change 0-1 at the end position.



**0x8300-05 - Homing target position**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-05	S32	R/W**	0	-8388608 ... 8388607	[user]	Homing target position

↳ 'Explanation of the elements' page 109

This object defines the target position for the homing and is signed. If the homing and the mechanical structure are configured correctly, this position should not be reached during homing. It thus serves for:

- set a maximum traversing position, if the initial position is not reached
- to specify the traversing direction by the sign

**0x8300-06 - Homing velocity V1**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-06	S32	R/W**	0	-8388608 ... 8388607	[user]	Homing velocity V1

↳ 'Explanation of the elements' page 109

This object specifies the search speed for traversing to the initial position. Homing *Mode 17* is a two step process.

1. ➤ With velocity V1 (0x8300-06) it is traversed toward the target position (0x8300-05) until the homing switch is overrun.
2. ➤ Then it is decelerated to speed 0 and again accelerated (0x8300-08 and 09) and moved in the negative direction at velocity V1.
3. ➤ If the reference switch is overrun again it is again slowed down and it is again accelerated in the positive direction at velocity V2 (0x8300-07).
4. ➤ With the third overrun of the homing switch the initial position (Offset: 0x8300-10) is set and moved to.

**0x8300-07 - Homing velocity V2**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-07	S32	R/W**	0	-8388608 ... 8388607	[user]	Homing velocity V2

↳ 'Explanation of the elements' page 109

This object specifies the velocity V2 for traversing to the initial position. The velocity V2 (0x8300-07) is used in the final stage of homing when approaching the initial position (offset: 0x8300-10).

Objects &gt; Homing - 0x8300

**0x8300-08 - Homing acceleration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-08	S32	R/W**	0	1000 ... 10000000	[user]	Homing acceleration

↳ *'Explanation of the elements' page 109*

This object specifies the value for the homing acceleration for traversing the initial position.

**0x8300-09 - Homing deceleration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-09	S32	R/W**	0	1000 ... 10000000	[user]	Homing deceleration

↳ *'Explanation of the elements' page 109*

This object specifies the value for the homing deceleration for traversing the initial position.

**0x8300-10 - Homing offset value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-10	S32	R/W**	0	-8388608 ... 8388607	[user]	Homing offset value

↳ *'Explanation of the elements' page 109*

This object specifies the offset between the zero position of the application and the reference point (by homing determined) of the drive. The value is to specify with sign. If the homing is completed and the initial position is reached, the offset is added to the initial position.

**0x8300-12 - Homing trq mode current**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-12	S16	R/W**	500	0 ... 15000	[mA]	Homing trq mode current

↳ *'Explanation of the elements' page 109*

This object specifies the current limit in the homing method -1 ↳ *'0x8300-02 - Homing method' page 131*. As soon as the limit is reached, the actual position is used as default position.

**0x8300-13 - Homing trq mode distance**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8300-13	S32	R/W**	1000	0 ... 100000	[user]	Homing trq mode distance

↳ 'Explanation of the elements' page 109

This object specifies a position offset, the motor is moved free, as soon as the current limit is reached with the homing method -1 ↳ '0x8300-02 - Homing method' page 131.

**5.2.12 Parameter for the PtP positioning profile - 0x8400****0x8400-00 - Positioning profile - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8400-00	U08	R	5	5		Positioning profile - number of entries

↳ 'Explanation of the elements' page 109

↳ Chap. 4.6 'PtP positioning profile' page 72

**0x8400-02 - Positioning profile target position**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8400-02*	S32	R/W**	0	-8388608 ... 8388607	[user]	Positioning profile target position

↳ 'Explanation of the elements' page 109

For the "PtP positioning profile" in this object the new target position is to be specified in user units. ↳ '0x8180-02 - Gear factor' page 128 You can find this object in the I/O area and it may not be written via the acyclic channel. The positioning is active, if:

- the operation mode "PtP positioning profile" is selected
- the System SLIO motion module is in state 'Operation enabled'

The positioning must not be started specifically by ↳ '0x8100-01 - Control word' page 121. During an ongoing positioning or after reaching the target position 0x8400-02 can be changed and it starts positioning to the new target value. For complete configuration of a positioning and to execute other objects of the index group 0x8400 are required.

**0x8400-03 - Positioning profile target velocity**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8400-03*	S32	R/W**	0	-8388608 ... 8388607	[user]	Positioning profile target velocity

↳ 'Explanation of the elements' page 109

This object specifies the speed for traversing to the initial position and is processed as absolute value. You can find this object in the I/O area and it may not be written via the acyclic channel. During a running positioning 0x8400-03 can be changed. It is directly accelerated or decelerated, provided the remaining room allows the positioning to the new target value.

Objects &gt; Positions and limit values - 0x8480

**0x8400-04 - Positioning profile target acceleration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8400-04*	S32	R/W**	10000	300 ... 100000000	[user]	Positioning profile target acceleration

↳ *'Explanation of the elements' page 109*

This object specifies the acceleration for traversing to the initial position and is processed as absolute value. You can find this object in the I/O area and it may not be written via the acyclic channel. During a running positioning 0x8400-04 can be changed and is immediately active.

**0x8400-05 - Positioning profile target deceleration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8400-05*	S32	R/W**	10000	300 ... 100000000	[user]	Positioning profile target deceleration

↳ *'Explanation of the elements' page 109*

This object specifies the deceleration for traversing to the initial position and is processed as absolute value. You can find this object in the I/O area and it may not be written via the acyclic channel. During a running positioning 0x8400-05 can be changed and is immediately active.

**5.2.13 Positions and limit values - 0x8480****0x8480-00 - Positions and limits - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-00	U08	R	16	16		Positions and limits - number of entries

↳ *'Explanation of the elements' page 109*

**0x8480-02 - Position actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-02*	S32	R	0	-8388608 ... 8388607	[user]	Position actual value

↳ *'Explanation of the elements' page 109*

This object specifies the value of the actual position. You can find this object in the I/O area and it may not be written via the acyclic channel. In open-loop operation, the object has an internally calculated value, not the current encoder value.

**0x8480-03 - Target position**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-03	S32	R	0	-8388608 ... 8388607	[user]	Target position

↳ 'Explanation of the elements' page 109

This object specifies the internal value of the target position at the input of the position controller. It is generated by the superior modules (e.g. PtP ramp generator).

**0x8480-05 - Software position limit positive direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-05	S32	R/W**	8388607	-8388608 ... 8388607	[user]	Software position limit positive direction

↳ 'Explanation of the elements' page 109

This object indicates the positive limit for the target position. Each target position is checked against this limit. Before matching always the reference offset ↳ '0x8300-10 - Homing offset value' page 134 is subtracted.

- Is a specified target position above the positive limit:
  - the positioning process is not performed
  - Bit 11: "Internal limitation active" in ↳ '0x8100-02 - Status word' page 122 is set
  - Bit 10: "Target position" reached in ↳ '0x8100-02 - Status word' page 122 is **not** set
  - Bit 9: in ↳ '0x8100-04 - Limit active bits' page 125 is set
- Is a measured actual position above the positive limit:
  - Bit 8: in ↳ '0x8100-04 - Limit active bits' page 125 is set

**0x8480-06 - Software position limit negative direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-06	S32	R/W**	-8388608	-8388608 ... 8388607	[user]	Software position limit negative direction

↳ 'Explanation of the elements' page 109

This object indicates the negative limit for the target position. Each target position is checked against this limit. Before matching always the reference offset 0x8300-10 is subtracted.

- Is a specified target position below the negative limit:
  - the positioning process is not performed
  - Bit 11: "Internal limitation active" in ↳ '0x8100-02 - Status word' page 122 is set
  - Bit 10: "Target position" reached in ↳ '0x8100-02 - Status word' page 122 is **not** set
  - Bit 9: in ↳ '0x8100-04 - Limit active bits' page 125 is set
- Is a measured actual position below the negative limit:
  - Bit 8: in ↳ '0x8100-04 - Limit active bits' page 125 is set

Objects &gt; Positions and limit values - 0x8480

**0x8480-07 - Range limit positive direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-07	S32	R/W	8000000	10000 ... 8388607	[user]	Range limit positive direction

↳ *'Explanation of the elements' page 109*

This object defines the positive overflow limit for the processing of position values. When this value is exceeded, the position values are set to [↳ '0x8480-08 - Range limit negative direction' page 138](#). Together with the object 0x8480-07 you can define a position range. For example, by presetting [↳ '0x8480-05 - Software position limit positive direction' page 137](#) and [↳ '0x8480-06 - Software position limit negative direction' page 137](#) out of the range you will get an endless movement, since the software limits can never be reached during the movement.

**0x8480-08 - Range limit negative direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-08	S32	R/W	-8000000	-8388608 ... -10000	[user]	Range limit negative direction

↳ *'Explanation of the elements' page 109*

This object defines the negative overflow limit for the processing of position values. When this value is exceeded, the position values are set to [↳ '0x8480-07 - Range limit positive direction' page 138](#). Together with the object 0x8480-08 you can define a position range. For example, by presetting [↳ '0x8480-05 - Software position limit positive direction' page 137](#) and [↳ '0x8480-06 - Software position limit negative direction' page 137](#) out of the range you will get an endless movement, since the software limits can never be reached during the movement.

**0x8480-09 - In-position window**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-09	S32	R/W**	10	-8388608 ... 8388607	[user]	In-position window

↳ *'Explanation of the elements' page 109*

This object specifies with relation to the target position a symmetrical range, within which the target position is reached.

**0x8480-10 - Lag error**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-10*	S32	R	0	-8388608 ... 8388607	[user]	Lag error

↳ *'Explanation of the elements' page 109*

This object contains the current system deviation as a deviation between target position and current value. This deviation is called *Lag error*. You can find this object in the I/O area.

**0x8480-11 - Lag error warning**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-11	S32	R/W**	100	-8388608 ... 8388607	[user]	Lag error warning

↳ 'Explanation of the elements' page 109

This object specifies a limit for the position difference (lag error). When the limit is reached, this is reported as a warning. ↳ '0x8100-02 - Status word' page 122  
↳ '0x8100-05 - Warnings active bits' page 126

**0x8480-12 - Lag error error**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-12	S32	R/W**	1000	-8388608 ... 8388607	[user]	Lag error error

↳ 'Explanation of the elements' page 109

This object specifies a limit for the position difference (lag error). When the limit is reached, this is reported as a error and the motion module switches to error status  
↳ '0x8100-02 - Status word' page 122 ↳ '0x8100-06 - Error active bits' page 127

**0x8480-13 - Position control P-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-13	U16	R/W**	500	0 ... 32000		Position control P-part

↳ 'Explanation of the elements' page 109

P-part of the position control

**0x8480-14 - Position control I-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-14	U16	R/W**	10	0 ... 32000		Position control I-part

↳ 'Explanation of the elements' page 109

I-part of the position control.

**0x8480-15 - Position control D-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-15	U16	R/W**	10	0 ... 32000		Position control D-part

↳ 'Explanation of the elements' page 109

D-part of the position control

Objects &gt; Velocities and limit values - 0x8500

**0x8480-16 - Position control shift factor**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8480-16	U16	R/W	12	0 ... 24		Position control shift factor

↳ 'Explanation of the elements' page 109

This parameter is used to limit the generated speed during the positioning. The smaller the value, the greater the limitation.

**5.2.14 Velocities and limit values - 0x8500****0x8500-00 - Velocity - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-00	U08	R	13	13		Velocity - number of entries

↳ 'Explanation of the elements' page 109

**0x8500-01 - Velocity control configuration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-01	U32	R/W	0	0 ... 0xFFFFFFFF		Velocity control configuration

↳ 'Explanation of the elements' page 109

With this object, you can disable the PtP position profile respectively the velocity profile for the velocity control. Here, the target velocity setting happens by the following objects:

- 0: Velocity control via PtP position profile and velocity profile with set point velocity setting via ↳ '0x8400-03 - Positioning profile target velocity' page 135. This is the default setting.
- 1: Velocity control exclusively velocity profile with set point velocity setting via ↳ '0x8500-03 - Velocity control target value' page 141.
- 2: PtP position profile and velocity profile are disabled with set point velocity setting as set point frequency for the PWM stage.

**0x8500-02 - Velocity control actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-02*	S32	R	0	-10000000 ... 10000000	[user]	Velocity control actual value

↳ 'Explanation of the elements' page 109

This object specifies the value of the actual velocity. You can find this object in the I/O area and it may not be written via the acyclic channel. In open-loop operation, the object has an internally calculated value, not determined from the current encoder value.



**0x8500-03 - Velocity control target value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-03	S32	R/W**	0	-10000000 ... 10000000	[user]	Velocity control target value

↳ 'Explanation of the elements' page 109

This object specifies the internal value of the target velocity at the input of the velocity controller. It is generated by the superior modules (e.g. PtP ramp generator).

**0x8500-04 - Velocity control limit positive direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-04	S32	R/W**	100000	0 ... 10000000	[user]	Velocity control limit positive direction

↳ 'Explanation of the elements' page 109

This object indicates the positive limit for velocity. Each target velocity is checked against this limit.

**0x8500-05 - Velocity control limit negative direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-05	S32	R/W**	-100000	-10000000 ... 0	[user]	Velocity control limit negative direction

↳ 'Explanation of the elements' page 109

This object indicates the negative limit for velocity. Each target velocity is checked against this limit.

**0x8500-06 - Velocity control range for torque limit**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-06	S32	R/W**	-20000	-1000000 ... 1000000	[user]	Velocity control range for torque limit

↳ 'Explanation of the elements' page 109

For the operating mode *Torque control* ↳ '0x8280-01 - Operating mode requested' page 130 here you can specify an area for the velocity limitation. This area is a measure for deceleration as soon as the corresponding limit value ↳ '0x8500-04 - Velocity control limit positive direction' page 141 respectively ↳ '0x8500-05 - Velocity control limit negative direction' page 141 is exceeded.

Objects &gt; Velocities and limit values - 0x8500

**0x8500-07 - Velocity control limit type for torque mode**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-07	U32	R/W**	0	0 ... 0xFFFFFFFF		Velocity control limit type for torque mode

[↪ 'Explanation of the elements' page 109](#)

- 0: Smooth velocity limit
  - The pre-set velocity limit [↪ '0x8500-04 - Velocity control limit positive direction' page 141](#) respectively [↪ '0x8500-05 - Velocity control limit negative direction' page 141](#) is always reached. When the limit is exceeded, no abrupt deceleration takes place. A slight overshoot is allowed. Here, the current set point is, dependent on the difference between current velocity and permissible limit range [↪ '0x8500-06 - Velocity control range for torque limit' page 141](#) linearly reduced to "0".
- 1: Hard velocity limit
  - The pre-set velocity limit [↪ '0x8500-04 - Velocity control limit positive direction' page 141](#) respectively [↪ '0x8500-05 - Velocity control limit negative direction' page 141](#) is reached with maximum permissible current. When the limit is exceeded, an abrupt deceleration takes place.

**0x8500-11 - Velocity control P-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-11	U16	R/W**	0	0 ... 65535		Velocity control P-part

[↪ 'Explanation of the elements' page 109](#)

P-part of the velocity control

**0x8500-12 - Velocity control I-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-12	U16	R/W**	0	0 ... 65535		Velocity control I-part

[↪ 'Explanation of the elements' page 109](#)

I-part of the velocity control

**0x8500-13 - Velocity control D-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8500-13	U16	R/W**	0	0 ... 65535		Velocity control D-part

[↪ 'Explanation of the elements' page 109](#)

D-part of the velocity control

## 5.2.15 Acceleration and deceleration - 0x8580

### 0x8580-00 - Acceleration and deceleration - number entries

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8580-00	U08	R	6	6		Acceleration and deceleration - number entries

↳ 'Explanation of the elements' page 109

### 0x8580-02 - Acceleration/Deceleration actual value

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8580-02*	S32	R	0	-100000000 ... 100000000	[user]	Acceleration/Deceleration actual value

↳ 'Explanation of the elements' page 109

This object specifies the value of the actual acceleration (positive sign) respectively deceleration (negative sign). You can find this object in the I/O area and it may not be written via the acyclic channel. In open-loop operation, the object has an internally calculated value, not determined from the current encoder value.

### 0x8580-03 - Deceleration quick stop value

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8580-03	S32	R/W**	10000	10 ... 100000000	[user]	Deceleration quick stop value

↳ 'Explanation of the elements' page 109

This object specifies the value of the target deceleration in case of a *quick stop*.

### 0x8580-04 - Acceleration limit

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8580-04	S32	R/W**	10000	10 ... 100000000	[user]	Acceleration limit

↳ 'Explanation of the elements' page 109

This object indicates the bidirectional limit value for the set point acceleration value. Each set point acceleration value is checked against this limit value. Please note that the lower limit is unequal 0. As soon as a set point velocity value is active, the movement starts, although the set point acceleration is 0.

Objects &gt; Currents - 0x8600

**0x8580-06 - Deceleration limit**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8580-06	S32	R/W**	10000	10 ... 100000000	[user]	Deceleration limit

↳ 'Explanation of the elements' page 109

This object indicates the bidirectional limit value for the set point deceleration value. Each set point deceleration value is checked against this limit value. Please note that the lower limit is unequal 0. As soon as a set point velocity value is active, the movement starts, although the set point deceleration is 0.

**5.2.16 Currents - 0x8600****0x8600-00 - CUR current number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-00	U08	R	21	21		Current - number of entries

↳ 'Explanation of the elements' page 109

**0x8600-02 - Current actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-02*	S16	R	0	-15000 ... 15000	[mA]	Current actual value

↳ 'Explanation of the elements' page 109

Effective value of the actual current of the winding in mA.

**0x8600-03 - Current target value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-03*	S16	R/W**	0	-15000 ... 15000	[mA]	Current set value

↳ 'Explanation of the elements' page 109

For the operating mode *Torque control* ↳ '0x8280-01 - Operating mode requested' page 130, here the effective value of the set point current can be defined. For all other operating modes, with this object you can define a dynamic current limit, which is limited only by ↳ '0x8C00-04 - Motor max. current' page 153. Here ↳ '0x8600-04 - Current limit positive direction' page 145 and ↳ '0x8600-05 - Current limit negative direction' page 145 have no effect.

**0x8600-04 - Current limit positive direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-04*	S16	R/W**	200	0 ... 15000	[mA]	Current limit positive direction

↳ 'Explanation of the elements' page 109

For the operating mode *Torque control* ↳ '0x8280-01 - Operating mode requested' page 130, here the effective value of the set point current can be defined. In all other operating modes this object is not considered.



Please note that this value must be symmetrical ↳ '0x8600-05 - Current limit negative direction' page 145!

**0x8600-05 - Current limit negative direction**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-05*	S16	R/W**	-200	-15000 ... 0	[mA]	Current limit negative direction

↳ 'Explanation of the elements' page 109

This object defines the limit value for the target current in negative direction.

Current limit positive/negative: Both values have the same magnitude, e.g. 0x8600-04 = 2000mA, 0x8600-05 = -2000mA. An asymmetric adjustment is not currently supported.

**0x8600-06 - Current control P-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-06	U16	R/W**	1000	0 ... 65535		Current control P-part

↳ 'Explanation of the elements' page 109

P-part of the current controller.

**0x8600-07 - Current control I-part**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-07	U16	R/W**	4000	0 ... 65535		Current control I-part

↳ 'Explanation of the elements' page 109

I-part of the current controller.

Objects &gt; Currents - 0x8600

**0x8600-09 - Current control filter factor**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-09	U16	R/W**	1	0 ... 7		Current control filter factor

↳ 'Explanation of the elements' page 109

To reduce high-frequency interferences at the current sensor, here you can set the filter factor of the low-pass filter for the current sensor.

**0x8600-10 - Current actual value winding A**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-10	S16	R	0	-15000 ... 15000	[mA]	Current actual value in winding

↳ 'Explanation of the elements' page 109

Effective value in mA of the actual current in winding.

**0x8600-12 - Current target value winding A**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-12	S16	R	0	-15000 ... 15000	[mA]	Current set value in winding


↳ 'Explanation of the elements' page 109

Effective value in mA of the set current in winding.

**0x8600-14 - Current offset  
value winding A**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-14	S16	R/W**	0	-500 ... 500	[mA]	Current offset value in winding

🔗 'Explanation of the elements' page 109



- 1 Output voltage
- 2 Current value
- 3 Ratio between current and voltage (I/U)
- 4 Set value
- 5 Offset
- 6 Output current


0x8600-14 - This object specifies the offset of the analog current actual value detection to 0 in winding.

0x8600-16 - This object specifies the ratio between current and voltage (I/U) of the analog current actual value detection in winding.

**0x8600-16 - Current voltage ratio winding A**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8600-16	S16	R/W**	4724	2000 ... 6000		Current voltage ratio in winding

↳ 'Explanation of the elements' page 109



- 1 Output voltage
- 2 Current value
- 3 Ratio between current and voltage (I/U)
- 4 Set value
- 5 Offset
- 6 Output current

0x8600-14 - This object specifies the offset of the analog current actual value detection to 0 in winding.

0x8600-16 - This object specifies the ratio between current and voltage (I/U) of the analog current actual value detection in winding.

To change this value is not usually required. Should this value be changed first, to avoid an error notification of the motion module, ↳ '0x8C00-04 - Motor max. current' page 153 should be set.

**5.2.17 Voltages - 0x8680****0x8680-00 - Voltages - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-00	U08	R	7	7		Voltages - number of entries

↳ 'Explanation of the elements' page 109



### 0x8680-02 - Power section supply voltage actual value

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-02	U16	R	0	0 ... 6000	[0.01V]	Power section supply voltage actual value

[↪ 'Explanation of the elements' page 109](#)

This object specifies the level of the actual supply voltage.

### 0x8680-04 - Power section supply voltage min. warning level

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-04	U16	R/W	4100	0 ... 6000	[0.01V]	Power section supply voltage min. warning level

[↪ 'Explanation of the elements' page 109](#)

This object specifies a lower limit for the supply voltage of the module. If the limit is exceeded, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-05 - Warnings active bits' page 126](#) a warning is shown.

### 0x8680-05 - Power section supply voltage max. warning level

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-05	U16	R/W	5500	0 ... 6000	[0.01V]	Power section supply voltage max. warning level

[↪ 'Explanation of the elements' page 109](#)

This object specifies an upper limit for the supply voltage of the module. If the limit is exceeded, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-05 - Warnings active bits' page 126](#) a warning is shown.

### 0x8680-06 - Power section supply voltage min. error level

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-06	U16	R/W	3800	0 ... 6000	[0.01V]	Power section supply voltage min. error level

[↪ 'Explanation of the elements' page 109](#)

This object specifies a lower limit for the supply voltage of the module. If the limit is under-shot, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-06 - Error active bits' page 127](#) an error is shown.

Objects &gt; Voltages - 0x8680

**0x8680-07 - Power section  
supply voltage max. error  
level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-07	U16	R/W	5800	0 ... 6000	[0.01V]	Power section supply voltage max. error level

[↪ 'Explanation of the elements' page 109](#)

This object specifies an upper limit for the supply voltage of the module. If the limit is exceeded, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-06 - Error active bits' page 127](#) an error is shown.

**0x8680-08 - Control  
voltage power stage  
actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-08	U16	R	0	0 ... 4000	[0.01V]	Control voltage power stage actual value

[↪ 'Explanation of the elements' page 109](#)

This object specifies the level of the actual supply voltage of the power stage.

**0x8680-10 - Control  
voltage power stage min.  
warning level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-10	U16	R/W	850	0 ... 4000	[0.01V]	Control voltage power stage min. warning level

[↪ 'Explanation of the elements' page 109](#)

This object specifies a lower limit for the control voltage of the power stage. If the limit is exceeded, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-05 - Warnings active bits' page 126](#) a warning is shown.

**0x8680-11 - Control  
voltage power stage max.  
warning level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-11	U16	R/W	1200	0 ... 4000	[0.01V]	Control voltage power stage max. warning level

[↪ 'Explanation of the elements' page 109](#)

This object specifies an upper limit for the control voltage of the power stage. If the limit is exceeded, via [↪ '0x8100-02 - Status word' page 122](#) respectively [↪ '0x8100-05 - Warnings active bits' page 126](#) a warning is shown.

**0x8680-12 - Control voltage power stage min. error level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-12	U16	R/W	800	0 ... 4000	[0.01V]	Control voltage power stage min. error level

↳ *'Explanation of the elements' page 109*

This object specifies a lower limit for the control voltage of the power stage. If the limit is undershot, via ↳ *'0x8100-02 - Status word' page 122* respectively ↳ *'0x8100-06 - Error active bits' page 127* an error is shown.

**0x8680-13 - Control voltage power stage max. error level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8680-13	U16	R/W	1400	0 ... 4000	[0.01V]	Control voltage power stage max. error level

↳ *'Explanation of the elements' page 109*

This object specifies an upper limit for the control voltage of the power stage. If the limit is exceeded, via ↳ *'0x8100-02 - Status word' page 122* respectively ↳ *'0x8100-06 - Error active bits' page 127* an error is shown.

**5.2.18 Temperatures - 0x8780****0x8780-00 - Temperatures - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-00	U08	R	12	12		Temperatures - number of entries

↳ *'Explanation of the elements' page 109*

**0x8780-02 - Temperature  $\mu$ -Controller actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-02	S16	R	0	-50 ... 120	[degC]	Temperature $\mu$ -Controller actual value

↳ *'Explanation of the elements' page 109*

This object specifies the measured temperature of the  $\mu$ -Controller of the motion module.

Objects &gt; Temperatures - 0x8780

**0x8780-03 - Temperature  
μ-Controller warning level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-03	S16	R/W	90	-50 ... 120	[degC]	Temperature μ-Controller warning level

↳ 'Explanation of the elements' page 109

This object specifies the temperature limit of the μ-Controller of the motion module. If the temperature limit is exceeded, via ↳ '0x8100-02 - Status word' page 122 respectively ↳ '0x8100-05 - Warnings active bits' page 126 a warning is shown.

**0x8780-04 - Temperature  
μ-Controller error level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-04	S16	R/W	105	-50 ... 120	[degC]	Temperature μ-Controller error level

↳ 'Explanation of the elements' page 109

This object specifies the temperature limit of the μ-Controller of the motion module. If the limit is reached, via ↳ '0x8100-02 - Status word' page 122 respectively ↳ '0x8100-06 - Error active bits' page 127 an error is shown and the status of the motion module changes to 'Fault reaction active'.

**0x8780-07 - Temperature  
power stage actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-07	S16	R	0	-50 ... 120	[degC]	Temperature power stage actual value

↳ 'Explanation of the elements' page 109

This object specifies the measured temperature of the internal power stage.

**0x8780-08 - Temperature  
power stage warning level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-08	S16	R/W	90	-50 ... 120	[degC]	Temperature power stage warning level

↳ 'Explanation of the elements' page 109

This object specifies a temperature limit for the internal power stage. If the temperature limit is exceeded, via ↳ '0x8100-02 - Status word' page 122 respectively ↳ '0x8100-05 - Warnings active bits' page 126 a warning is shown.

**0x8780-09 - Temperature power stage error level**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8780-09	S16	R/W	105	-50 ... 120	[degC]	Temperature power stage error level

↳ 'Explanation of the elements' page 109

This object specifies a temperature limit for the internal power stage. If the temperature limit is reached, via ↳ '0x8100-02 - Status word' page 122 respectively ↳ '0x8100-06 - Error active bits' page 127 an error is shown and the status of the motion module changes to 'Fault reaction active'.

**5.2.19 Motor data - 0x8C00****0x8C00-00 - Motor data - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-00	U08	R	10	10		Motor data - number of entries

↳ 'Explanation of the elements' page 109

**0x8C00-04 - Motor max. current**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-04	U16	R/W	500	0 ... 15000	[mA]	Motor max. current

↳ 'Explanation of the elements' page 109

This object specifies the maximum effective value of the motor current and must be configured. Exceeds the actual current in operation this value, there is a fault response of the motion module, which is shown in ↳ '0x8100-02 - Status word' page 122 respectively ↳ '0x8100-06 - Error active bits' page 127 bit 0.

**0x8C00-06 - Motor nominal velocity**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-06	U16	R/W	0	0 ... 32000	[rpm]	Motor nominal velocity

↳ 'Explanation of the elements' page 109

Details can be found in the data sheet of your motor.

Objects &gt; Encoder resolution - 0x8F00

**0x8C00-07 - Motor max. velocity**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-07	U16	R/W	3000	0 ... 32000	[rpm]	Motor max. velocity

[↪ 'Explanation of the elements' page 109](#)

This object specifies the max. velocity of the motor and must be configured. At this velocity, the output of the position controller is limited and will not be used to monitor the actual velocity.

**0x8C00-09 - Motor velocity constant**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-09	U16	R/W	1000	0 ... 65535	[0.1rpm/V]	Motor velocity constant

[↪ 'Explanation of the elements' page 109](#)

Details can be found in the data sheet of your motor.

**0x8C00-10 - Motor phase resistance**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8C00-10	U16	R/W	0	0 ... 65535	[mΩ]	Motor phase resistance

[↪ 'Explanation of the elements' page 109](#)

Details can be found in the data sheet of your motor.

**5.2.20 Encoder resolution - 0x8F00****0x8F00-00 - Encoder - number of entries**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8F00-00	U08	R	3	3		Encoder - number of entries

[↪ 'Explanation of the elements' page 109](#)

**0x8F00-01 - Encoder Feed-back configuration**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8F00-01	U32	R/W	0	0 ... 1		Encoder feedback configuration drive 1 Configuration I/O1 and I/O3

↳ 'Explanation of the elements' page 109

With this object the digital in-/outputs I/O1 and I/O3 are physically configured as encoder input.

- 0: Encoder functionality for I/O1 and I/O3 is disabled
- 1: Encoder functionality for I/O1 and I/O3 is enabled
  - 24V HTL signal
  - Phase A and B
  - 100 kHz
  - 4-fold evaluation



*If there is no more encoder connected, the unused digital in-/outputs I/O2 and I/O4 are further free for usage.*

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x9F00-01	U32	R/W	0	0 ... 1		Encoder feedback configuration drive 2 Configuration I/O2 and I/O4

↳ 'Explanation of the elements' page 109

With this object the digital in-/outputs I/O2 and I/O4 are physically configured as encoder input.

- 0: Encoder functionality for I/O2 and I/O4 is disabled
- 1: Encoder functionality for I/O2 and I/O4 is enabled
  - 24V HTL signal
  - Phase A and B
  - 100 kHz
  - 4-fold evaluation

**0x8F00-02 - Encoder actual value**

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8F00-02	U16	R	0	0 ... 65535	[inc]	Encoder current value

↳ 'Explanation of the elements' page 109

With this object you can get the actual value of a possibly connected encoder. When using the ↳ *Chap. 4.6 'PtP positioning profile' page 72*, via ↳ *'0x8F00-01 - Encoder Feedback configuration' page 155* you can define the use of the encoder signal.

---

Objects > Encoder resolution - 0x8F00

### 0x8F00-03 - Encoder resolution

Index-Sub	Type	RW	Default	Value range	Unit	Description
0x8F00-03	U16	R/W	4000	0 ... 65535	[inc/rot]	Encoder resolution

🔗 *'Explanation of the elements' page 109*

With this object, you can configure the encoder resolution of the connected encoder. The encoder resolution defines the number of pulses per rotation.